



- 1** Position above template at desired height and mark "A" and "B" locations on door. Standard location is approximately 30 inches from bottom of door.
- 2** Drill 1/2-inch through holes at "A" locations.
- 3** Using a saw, connect the 4 holes.
- 4** Drill 3/32-inch pilot holes 1/2-inch deep at "B" locations for front and back plates and fasten with included screws. Only clean with soft cloth, mild soap and water.