



Federal Brace
BEAUTIFULLY CRAFTED CONFIDENT SUPPORT

COUNTERTOP BRACKET | *Torii*



TORII COUNTERTOP BRACKET INSTALLATION INSTRUCTIONS

Every successful countertop installation begins with good planning and action. Do not wait until the last minute to order your countertop supports, fasteners or adhesives for installation. Make sure that all aspects of the support substructure are considered and discussed to ensure that your countertop installation will be smooth and that your countertop support products will be sufficient.

Note this installation document should not be considered a specific recommendation for your particular application. Federal Brace cannot provide installation guidelines to meet the particulars of every application. This document should be considered a help sheet that provides considerations about the general characteristics of a particular type of support and installation.

Characteristics of the Torii Style Countertop Support Bracket

Our Torii Countertop Brackets are designed to provide the strength that comes from a gusseted metal bracket. The material thickness of the Torii Bracket is 1/4" and the gusset provides additional resistance to deflection.

The Torii style countertop bracket is suggested for use in all standard applications where a countertop bracket is used – island extension, half wall or pony wall applications and wall shelf mounted. The Torii is not useful in the elevated countertop application.

Preparations for the Torii Bracket

The Torii Countertop Supports come in brushed stainless steel and raw steel. If you have ordered your Torii Brackets unfinished (without paint) you will need to finish them before

installation. Make sure you clean the bracket of any machine oil or rust preventative before painting. Once clean and dry apply a metal compatible paint to the bracket completely. Let the first coat dry, then apply at least 1 more coat. Before installing the bracket, the paint should be allowed to dry completely.

Considerations when Installing Torii Style Countertop Brackets

Whenever installing the Torii Countertop Brackets make sure that you provide the thickest possible substructure (at least 3/4") on which to fasten the bracket. You will want the fasteners to have as much "biting" material as - possible. (This will provide a secure fastening of the brackets.) Also, the substructure should be tied into the floor. Remember, a weak substructure makes for a weak installation.

With the substructure in place and sturdy, measure out your bracket pattern. We suggest that you space the Torii style bracket no greater than 30" apart on a standard application. Once you have your bracket support pattern set up you can attach your first bracket to the substructure. Make sure that when you fasten your bracket that you check for level in all directions. The bracket should be straight up and down and level vertically as well as horizontally. This will give the best possible result to your countertop.

The top of your bracket should not extend over your support substructure but should meet flush with the top. You will want to use a level to determine the positioning of the top of the bracket to the top of your substructure. When manufacturing the Torii Countertop Supports we attempt to hit the angle break at 90 degrees 100% of the time. However, we may be slightly off of that mark. If this is the case with your bracket, you should use shims in your installation to bring the bracket to level. Shims can be placed directly behind the down flange or you may need to slightly plane the support stud to allow for the bracket to sit flush and level.

Once all the brackets are in place, you will want to wipe them down to get rid of any handprints or other debris. Just before installation of your counter you need to apply adhesive or

silicone to the top of the bracket to adhere it to the counter. Once the counter is in place, you can caulk around the edge of the brackets if you choose. This will give greater adherence to the countertop and cover any gap between the brackets and counter.

Final step is to enjoy your work and your new kitchen counter. We are happy that you chose to support your beautiful counters with Federal Brace brackets. We would be thankful if you would send us images of your new kitchen and our brackets under your counters. We enjoy seeing Federal Brace supports at work. Also, know that the highest compliment Federal Brace can be given is a reference from our customers to friends and family. If you have enjoyed your buying experience with Federal Brace please let someone know.

For any questions or comments please to contact us by email at customerservice@federalbrace.com or by phone at (877) 353-8899. If you are a visual learner, check out our installation videos on our YouTube channel Don't forget to share your projects with your new Federal Brace brackets on Twitter and Instagram, just tag us @FederalBrace. Like us on Facebook, and check out our boards on Pinterest for more home improvement/decor and DIY project ideas.

