

on the mounting bracket again, and turn the canopy ring

clockwise until tight.

1) Use the Mounting Bracket as a guide, mark the spots where the 4 Self Tapping Screws will be drilled.

2) Remove the Mounting Bracket, drill 4 holes for 3MM diameter, install the mounting bracket onto wooden ceiling with the 4Self Tapping Screws & Washers

INSTALLATION INSTRUCTION

1H	Auto off after 1hr
2H	Auto off after 2hr
4H	Auto off after 4hr
8H	Auto off after 8hr

Fanchange dirsction.(capprox.02sec)