



**Leakno Premium Toilet Mounting Bolts & Hardware**  
(Included)



**Optional Leakno Premium Spacer for floors up to 1/2 inch below surface**  
(Included)

## 3 EASY STEPS - INSTALL IN JUST A FEW MINUTES

Remove the paper film from the adhesive on the Leakno Wax-Free Toilet seal



Place the seal onto the discharge opening and press down firmly to ensure that the seal is attached



Set toilet bowl in place and tighten the anchors. That's it!



\* For flanges up to 1/2 inch below surface, use the included Leakno Premium Slide-On Spacer

**NO WAX | NO MESS**

**NO MORE LEAKS, GURANTEED !**

