


Assembly Instruction

————— BED137 —————



General Guidelines

- Please read the following instruction carefully and use the product accordingly.
- Please keep this manual and hand it over when you transfer the product.
- This summary may not include every detail of all variations and considered steps. Please contact us when further information and help are needed.


Notes

- The product is intended for indoor use only. The product must be assembled and used in accordance with the provisions of the manual. Personal injury and/or damage to product may occur if products are used outside of their intended purposes and/or if products have been changed/modified from their original design. The seller does not assume any responsibility or liability with respect to any injury/damage caused by incorrect assembly or improper use.
- Avoid long-term exposure to humid environments to prevent mildew.
- Keep the product away from fire sources and high temperatures. Do not expose the product to direct sunlight.
- Do not place any hot objects on the surface of the product.
- If there are any defective or missing parts after unpacking, please cease assembly immediately and contact us.
- Please assemble the item on a spacious surface and do not place the unwrapped product directly on the ground to avoid product damage.
- Please do not stand or sit on the wooden boards.
- Please wear gloves during the assembly and/or disassembly process to avoid scratches from any sharp edges.
- Please match the corresponding part and fitting based on the part number in the manual.
- If the part does not match with the fitting, please check the piece as specified in this manual.
- During assembly, first loosely align all screws with the corresponding pre-drilled holes and then tighten the screws one by one.
- Periodically inspect screw tightness while the product is in use. If necessary, retighten to ensure structural integrity.
- If you accidentally spill water or another liquid on the surface, immediately wipe clean with a dry towel.
- Please keep the product away from sharp, pointed objects and corrosive substances to prevent product damage.
- Please place this item on level, solid ground during use.






Warnings

- During assembly, keep all small parts out of the reach of children. It may be fatal if swallowed or inhaled.
- Children should not climb or play on the product in order to avoid tipping over the furniture and causing serious injury.
- To avoid the potential dangers of suffocation, please keep all parts and packaging (film, plastic bags, foam, etc.) away from babies and children.
- Keep sharp objects and corrosive items away from the product to avoid any damage or injury.
- Do not shake or move violently during use to avoid tipping over the product.

Parts List (EN)






















Parts List (EN)







① 1PCS	② 1PCS	③ 1PCS	④ 1PCS
⑤ 1PCS	⑥ 1PCS	⑦ 2PCS	⑧ 1PCS
⑨ 1PCS	⑩ 1PCS	⑪ 1PCS	⑫ 1PCS
⑬ 1PCS	⑭ 1PCS	⑮ 1PCS	⑯ 2PCS
⑰ 1PCS	⑱ 1PCS	⑲ 1PCS	⑳ 1PCS

















Parts List (EN)




21  1PCS	22  1PCS	23  1PCS	24  4PCS
25  1PCS	26  1PCS	27  1PCS	28  13PCS
29  25PCS	30  6PCS	31  1PCS	32  1PCS
33  1PCS	34  24PCS	35  1PCS	36  1PCS
37  3PCS			

Parts List (EN)




A  M8*55 4PCS	B  M8*15 2PCS	C  M6*45 11PCS	D  M6*30 13PCS
E  M6*10 11PCS	F  M6*12 65PCS	G  3.5*30 6PCS	H  3.5*18 7PCS
I  Ø6*70mm 5PCS	J  Ø6*35mm 15PCS	K  Ø8*30 23PCS	L  Ø15*9 26PCS
M  M11*14 4PCS	N  Ø8*19 4PCS	O  Ø6*19 26PCS	P  M4 1PCS
Q  M5 1PCS	R  1PCS	S  1PCS	

Instructions For Fastening CAM-BOLT and CAM-LOCK




CAM-BOLT




CAM-LOCK


Tools Required




INSERTING AND TIGHTENING CAM-BOLT



Place Cam-bolt on pre-drilled hole and screw in vertically




Shoulder is flushed (on the same level) with the panel.



Shoulder is above the panel.


Place Cam-bolt on the designated pre-drilled holes on the panel. Use a Phillips Screwdriver to screw-in Cam-bolt vertically until shoulder is flushed (on the same level) with panel.

INSERTING CAM-LOCK



Align the arrow on the Cam-lock to the Cam-bolt head and insert the Cam-lock. Ensure Cam-lock is fully inserted.

TIGHTENING CAM-LOCK




Use a Flat-head Screwdriver to turn Camlock clockwise so it locks onto the head of the Cam-bolt. Turn until it is snug (about 3/4ths of a turn) -- over-tightening could damage Cam-lock or/and Cam-bolt.


STEP 1

Note: The side with the screws is on the outside.

	I×3PCS
	K×2PCS
	L×6PCS








STEP 2





	D×8PCS
---	--------

STEP 3




	J×6PCS
	K×4PCS
	L×6PCS

STEP 4




	D×4PCS
	H×6PCS

STEP 5





	G×5PCS
---	--------

STEP 6



	37#×1PCS
	F×4PCS
	I×2PCS
	K×2PCS
	L×4PCS

STEP 7



16




16

16

15






14

16




	J×4PCS
	K×4PCS
	L×4PCS

STEP 8




	J×4PCS
	K×4PCS
	L×4PCS

STEP 9




	30#×2PCS
	F×8PCS
	O×8PCS

STEP 10




	K×4PCS
--	--------


STEP 11



STEP 12




STEP 13



	A×4PCS
	M×4PCS
	N×4PCS


Note: When assembling, first insert the M accessory into the board, then tighten the screw. Note that the direction of the M parts should be aligned with hole position. If the screws cannot be locked, you can twist the M parts.

STEP 14



	35#×1PCS
	F×8PCS


STEP 15



	24#×4PCS
	B×2PCS
	F×8PCS


STEP 16

Flip the entire iron frame to install component 30, pay attention to the direction of component 30!!!




	30#×4PCS
	F×16PCS
	O×16PCS

STEP 17




STEP 18




	F×4PCS
---	--------


STEP 19




STEP 20



STEP 21



First take off the screw and then put on the air pressure rod and lock the screw.



STEP 22

