

# Microwave

FFCE2278L S



## Signature Features

### Sensor One-Touch Options

Microwave automatically adjusts power levels and cooking times to cook a variety of items, effortlessly.

### Melt & Soften

Use the microwave to quickly melt or soften butter or cheeses for your recipes.

### One-Touch Keep Warm Setting

Keep food warm until everything — and everyone — is ready.

### Easy-Set™ Start

Quickly start cooking — one to six minutes — with just one touch.

## Countertop

### Product Dimensions

|        |         |
|--------|---------|
| Height | 13-7/8" |
| Width  | 24"     |
| Depth  | 21-3/8" |

### More Easy-To-Use Features

#### Ready-Select® Controls

Easily select options with the touch of a button.

#### Auto One-Touch Options

Our microwaves feature easy-to-use one-touch buttons so you can cook beverages, baked potatoes, popcorn, fresh veggies or even add thirty seconds with the touch of a button.

#### Effortless™ Defrost

Makes it easy to defrost almost anything, quickly and evenly.

#### Effortless™ Reheat

Reheat almost anything at the touch of a button.

#### Multi-Stage Cooking

Our Multi-Stage Cooking option allows you to program power levels and cooking times in advance, so you can program it to defrost, cook and keep a meal warm all at once.

#### 10 Cooking Power Levels

Provides the versatility needed to prepare everything from frozen pizza to pot roast quickly and easily.

#### Control Lock Option

#### Electronic Clock/Timer

Helps you keep track of cook times.

#### Attractive Stainless Steel Exterior

#### Interior Light

Illuminates the contents of the microwave for increased visibility.

#### Large Glass Turntable


Even large items fit on our large glass turntable.

#### Available in:



Stainless  
(S)

| Features                         |                   |
|----------------------------------|-------------------|
| Control/ Timing System           | Ready-Select®     |
| Exterior Door Finish             | Stainless Steel   |
| Handle Design                    | Push Button       |
| Microwave Features               |                   |
| Microwave Capacity (Cu.Ft.)      | 2.2               |
| Watts (IEC-705 Test Procedure)   | 1,200             |
| Interior Light                   | Yes               |
| Interior Color                   | White             |
| Turntable Diameter               | 16"               |
| Turntable On/Off                 | Yes               |
| Control Lock                     | Yes               |
| Clock                            | Yes               |
| Touch Pad Buttons                | 23                |
| Power Levels                     | 10                |
| Accessory Metal Rack             |                   |
| Microwave Control Options        |                   |
| Easy-Set™ Start                  | Yes               |
| Popcorn Button                   | Yes               |
| Chicken Nugget Button            |                   |
| Baked Potato Button              | Yes               |
| Sensor Reheat Button             | Yes               |
| Snack Button                     |                   |
| Beverage                         | Yes               |
| Melt & Soften Options            | 4 / 4             |
| Auto Reheat Options              |                   |
| Snack Menu Options               |                   |
| Auto Cook Options                |                   |
| Auto Defrost Options             | Yes               |
| Keep Warm                        | Yes               |
| Add-30-Seconds                   | Yes               |
| Sensor Cooking Options           | 7                 |
| Vegetable Cook Sensor            | Yes               |
| Delay Start                      |                   |
| User Preferences                 |                   |
| Power Ratings                    |                   |
| Frequency (Mhz)                  | 2,450             |
| Watts @ 120 Volts                | 1,200             |
| Amps @ 120 Volts                 | 13                |
| Specifications                   |                   |
| Oven Interior Height             | 11-1/2"           |
| Oven Interior Width              | 17-1/16"          |
| Oven Interior Depth              | 18-15/16"         |
| Power Supply Connection Location | Rear              |
| Voltage Rating                   | 120V / 60Hz / 15A |
| Minimum Circuit Required (Amps)  | 15                |
| Shipping Weight (Approx.)        | 49 Lbs.           |



NOTE: For planning purposes only. Always consult local and national electric codes. Refer to Product Installation Guide for detailed installation instructions on the web at [frigidaire.com](http://frigidaire.com).



| Product Dimensions <sup>1</sup> |         |
|---------------------------------|---------|
| A - Height                      | 13-7/8" |
| B - Width                       | 24"     |
| C - Depth                       | 21-3/8" |

<sup>1</sup>A minimum clearance of 3 inches is required between microwave oven and adjacent walls. Leave a minimum clearance of 12 inches above microwave oven.

Accessories information available on the web at [frigidaire.com](http://frigidaire.com)