


# QUICK SHIP COLONIAL FAUXWOOD & BASSWOOD INTERIOR SHUTTERS

## MOUNTING: INSIDE MOUNT

### 1 Measure window and select correct shutter size

- Measure top, middle, bottom.
- Use the narrowest width.
- Measure exact window height.


Using the chart, select the shutter size that best matches your measurements.



### 2 Select shutter configuration


#### Single Hung

A single shutter covers the entire height of the window opening.



#### Café

The height of the shutter is less than the full height of the window opening.



		Window Opening Width					
		23" - 25"	27" - 29"	29" - 31"	31" - 33"	35" - 37"	39" - 41"
Window Opening Length / Height	17 3/4" - 20"	<b>Shutter Size</b> 23" - 25"(w) x 20"(h) <b>Fauxwood Model Number</b> TW1001QS White TK1001QS Golden Oak <b>Basswood Model Number</b> TD1001QS Mahogany TG1001QS Golden	<b>Shutter Size</b> 27" - 29"(w) x 20"(h) <b>Fauxwood Model Number</b> TW1006QS White TK1006QS Golden Oak <b>Basswood Model Number</b> TD1006QS Mahogany TG1006QS Golden	<b>Shutter Size</b> 29" - 31"(w) x 20"(h) <b>Fauxwood Model Number</b> TW1011QS White TK1011QS Golden Oak	<b>Shutter Size</b> 31" - 33"(w) x 20"(h) <b>Fauxwood Model Number</b> TW1016QS White TK1016QS Golden Oak	<b>Shutter Size</b> 35" - 37"(w) x 20"(h) <b>Fauxwood Model Number</b> TW1021QS White TK1021QS Golden Oak	<b>Shutter Size</b> 39" - 41"(w) x 20"(h) <b>Fauxwood Model Number</b> TW1026QS White TK1026QS Golden Oak
	21 3/4" - 24"	<b>Shutter Size</b> 23" - 25"(w) x 24"(h) <b>Fauxwood Model Number</b> TW1002QS White TK1002QS Golden Oak <b>Basswood Model Number</b> TD1002QS Mahogany TG1002QS Golden	<b>Shutter Size</b> 27" - 29"(w) x 24"(h) <b>Fauxwood Model Number</b> TW1007QS White TK1007QS Golden Oak <b>Basswood Model Number</b> TD1007QS Mahogany TG1007QS Golden	<b>Shutter Size</b> 29" - 31"(w) x 24"(h) <b>Fauxwood Model Number</b> TW1012QS White TK1012QS Golden Oak <b>Basswood Model Number</b> TD1012QS Mahogany TG1012QS Golden	<b>Shutter Size</b> 31" - 33"(w) x 24"(h) <b>Fauxwood Model Number</b> TW1017QS White TK1017QS Golden Oak <b>Basswood Model Number</b> TD1017QS Mahogany TG1017QS Golden	<b>Shutter Size</b> 35" - 37"(w) x 24"(h) <b>Fauxwood Model Number</b> TW1022QS White TK1022QS Golden Oak <b>Basswood Model Number</b> TD1022QS Mahogany TG1022QS Golden	<b>Shutter Size</b> 39" - 41"(w) x 24"(h) <b>Fauxwood Model Number</b> TW1027QS White TK1027QS Golden Oak
	25 3/4" - 28"	<b>Shutter Size</b> 23" - 25"(w) x 28"(h) <b>Fauxwood Model Number</b> TW1003QS White TK1003QS Golden Oak <b>Basswood Model Number</b> TD1003QS Mahogany TG1003QS Golden	<b>Shutter Size</b> 27" - 29"(w) x 28"(h) <b>Fauxwood Model Number</b> TW1008QS White TK1008QS Golden Oak <b>Basswood Model Number</b> TD1008QS Mahogany TG1008QS Golden	<b>Shutter Size</b> 29" - 31"(w) x 28"(h) <b>Fauxwood Model Number</b> TW1013QS White TK1013QS Golden Oak <b>Basswood Model Number</b> TD1013QS Mahogany TG1013QS Golden	<b>Shutter Size</b> 31" - 33"(w) x 28"(h) <b>Fauxwood Model Number</b> TW1018QS White TK1018QS Golden Oak <b>Basswood Model Number</b> TD1018QS Mahogany TG1018QS Golden	<b>Shutter Size</b> 35" - 37"(w) x 28"(h) <b>Fauxwood Model Number</b> TW1023QS White TK1023QS Golden Oak <b>Basswood Model Number</b> TD1023QS Mahogany TG1023QS Golden	<b>Shutter Size</b> 39" - 41"(w) x 28"(h) <b>Fauxwood Model Number</b> TW1028QS White TK1028QS Golden Oak <b>Basswood Model Number</b> TD1028QS Mahogany TG1028QS Golden
	29 3/4" - 32"	<b>Shutter Size</b> 23" - 25"(w) x 32"(h) <b>Fauxwood Model Number</b> TW1004QS White TK1004QS Golden Oak <b>Basswood Model Number</b> TD1004QS Mahogany TG1004QS Golden	<b>Shutter Size</b> 27" - 29"(w) x 32"(h) <b>Fauxwood Model Number</b> TW1009QS White TK1009QS Golden Oak	<b>Shutter Size</b> 29" - 31"(w) x 32"(h) <b>Fauxwood Model Number</b> TW1014QS White TK1014QS Golden Oak <b>Basswood Model Number</b> TD1014QS Mahogany TG1014QS Golden	<b>Shutter Size</b> 31" - 33"(w) x 32"(h) <b>Fauxwood Model Number</b> TW1019QS White TK1019QS Golden Oak <b>Basswood Model Number</b> TD1019QS Mahogany TG1019QS Golden	<b>Shutter Size</b> 35" - 37"(w) x 32"(h) <b>Fauxwood Model Number</b> TW1024QS White TK1024QS Golden Oak <b>Basswood Model Number</b> TD1024QS Mahogany TG1024QS Golden	<b>Shutter Size</b> 39" - 41"(w) x 32"(h) <b>Fauxwood Model Number</b> TW1029QS White TK1029QS Golden Oak
	33 3/4" - 36"	<b>Shutter Size</b> 23" - 25"(w) x 36"(h) <b>Fauxwood Model Number</b> TW1004QS White TK1004QS Golden Oak	<b>Shutter Size</b> 27" - 29"(w) x 36"(h) <b>Fauxwood Model Number</b> TW1010QS White TK1010QS Golden Oak <b>Basswood Model Number</b> TD1010QS Mahogany TG1010QS Golden	<b>Shutter Size</b> 29" - 31"(w) x 36"(h) <b>Fauxwood Model Number</b> TW1015QS White TK1015QS Golden Oak	<b>Shutter Size</b> 31" - 33"(w) x 36"(h) <b>Fauxwood Model Number</b> TW1020QS White TK1020QS Golden Oak <b>Basswood Model Number</b> TD1020QS Mahogany TG1020QS Golden	<b>Shutter Size</b> 35" - 37"(w) x 36"(h) <b>Fauxwood Model Number</b> TW1025QS White TK1025QS Golden Oak <b>Basswood Model Number</b> TD1025QS Mahogany TG1025QS Golden	<b>Shutter Size</b> 39" - 41"(w) x 36"(h) <b>Fauxwood Model Number</b> TW1030QS White TK1030QS Golden Oak


# QUICK SHIP COLONIAL FAUXWOOD & BASSWOOD INTERIOR SHUTTERS

## MOUNTING: OUTSIDE MOUNT

### 1 Measure window and select correct shutter size

Measure the width from point to point on your molding or wall where our frame will be hung (a minimum of 3/4 in. flat space is needed where the frame will be hung).

Measure the height from point to point on your molding or wall where our frame will be hung. If you have a window sill, measure from the top of the sill to the point on your molding or wall where the frame will be hung (a minimum of 3/4 in. flat space is needed where the frame will be hung).




### 2 Select shutter configuration

**Single Hung**  
A single shutter covers the entire height of the window opening.



**Café**  
The height of the shutter is less than the full height of the window opening.



		Window Opening Width					
		18 1/2" - 20 1/2"	22 1/2" - 24 1/2"	24 5/8" - 26 1/2"	26 5/8" - 28 1/2"	30 1/2" - 32 1/2"	34 1/2" - 36 1/2"
Window Opening Length/Height	17 3/4" - 20"	<b>Shutter Size</b> 23" - 25"(w) x 20"(h) <b>Fauxwood Model Number</b> TW1001QS White TK1001QS Golden Oak <b>Basswood Model Number</b> TD1001QS Mahogany TG1001QS Golden	<b>Shutter Size</b> 27" - 29"(w) x 20"(h) <b>Fauxwood Model Number</b> TW1006QS White TK1006QS Golden Oak <b>Basswood Model Number</b> TD1006QS Mahogany TG1006QS Golden	<b>Shutter Size</b> 29" - 31"(w) x 20"(h) <b>Fauxwood Model Number</b> TW1011QS White TK1011QS Golden Oak	<b>Shutter Size</b> 31" - 33"(w) x 20"(h) <b>Fauxwood Model Number</b> TW1016QS White TK1016QS Golden Oak	<b>Shutter Size</b> 35" - 37"(w) x 20"(h) <b>Fauxwood Model Number</b> TW1021QS White TK1021QS Golden Oak	<b>Shutter Size</b> 39" - 41"(w) x 20"(h) <b>Fauxwood Model Number</b> TW1026QS White TK1026QS Golden Oak
	21 3/4" - 24"	<b>Shutter Size</b> 23" - 25"(w) x 24"(h) <b>Fauxwood Model Number</b> TW1002QS White TK1002QS Golden Oak <b>Basswood Model Number</b> TD1002QS Mahogany TG1002QS Golden	<b>Shutter Size</b> 27" - 29"(w) x 24"(h) <b>Fauxwood Model Number</b> TW1007QS White TK1007QS Golden Oak <b>Basswood Model Number</b> TD1007QS Mahogany TG1007QS Golden	<b>Shutter Size</b> 29" - 31"(w) x 24"(h) <b>Fauxwood Model Number</b> TW1012QS White TK1012QS Golden Oak <b>Basswood Model Number</b> TD1012QS Mahogany TG1012QS Golden	<b>Shutter Size</b> 31" - 33"(w) x 24"(h) <b>Fauxwood Model Number</b> TW1017QS White TK1017QS Golden Oak <b>Basswood Model Number</b> TD1017QS Mahogany TG1017QS Golden	<b>Shutter Size</b> 35" - 37"(w) x 24"(h) <b>Fauxwood Model Number</b> TW1022QS White TK1022QS Golden Oak <b>Basswood Model Number</b> TD1022QS Mahogany TG1022QS Golden	<b>Shutter Size</b> 39" - 41"(w) x 24"(h) <b>Fauxwood Model Number</b> TW1027QS White TK1027QS Golden Oak
	25 3/4" - 28"	<b>Shutter Size</b> 23" - 25"(w) x 28"(h) <b>Fauxwood Model Number</b> TW1003QS White TK1003QS Golden Oak <b>Basswood Model Number</b> TD1003QS Mahogany TG1003QS Golden	<b>Shutter Size</b> 27" - 29"(w) x 28"(h) <b>Fauxwood Model Number</b> TW1008QS White TK1008QS Golden Oak <b>Basswood Model Number</b> TD1008QS Mahogany TG1008QS Golden	<b>Shutter Size</b> 29" - 31"(w) x 28"(h) <b>Fauxwood Model Number</b> TW1013QS White TK1013QS Golden Oak <b>Basswood Model Number</b> TD1013QS Mahogany TG1013QS Golden	<b>Shutter Size</b> 31" - 33"(w) x 28"(h) <b>Fauxwood Model Number</b> TW1018QS White TK1018QS Golden Oak <b>Basswood Model Number</b> TD1018QS Mahogany TG1018QS Golden	<b>Shutter Size</b> 35" - 37"(w) x 28"(h) <b>Fauxwood Model Number</b> TW1023QS White TK1023QS Golden Oak <b>Basswood Model Number</b> TD1023QS Mahogany TG1023QS Golden	<b>Shutter Size</b> 39" - 41"(w) x 28"(h) <b>Fauxwood Model Number</b> TW1028QS White TK1028QS Golden Oak <b>Basswood Model Number</b> TD1028QS Mahogany TG1028QS Golden
	29 3/4" - 32"	<b>Shutter Size</b> 23" - 25"(w) x 32"(h) <b>Fauxwood Model Number</b> TW1004QS White TK1004QS Golden Oak <b>Basswood Model Number</b> TD1004QS Mahogany TG1004QS Golden	<b>Shutter Size</b> 27" - 29"(w) x 32"(h) <b>Fauxwood Model Number</b> TW1009QS White TK1009QS Golden Oak	<b>Shutter Size</b> 29" - 31"(w) x 32"(h) <b>Fauxwood Model Number</b> TW1014QS White TK1014QS Golden Oak <b>Basswood Model Number</b> TD1014QS Mahogany TG1014QS Golden	<b>Shutter Size</b> 31" - 33"(w) x 32"(h) <b>Fauxwood Model Number</b> TW1019QS White TK1019QS Golden Oak <b>Basswood Model Number</b> TD1019QS Mahogany TG1019QS Golden	<b>Shutter Size</b> 35" - 37"(w) x 32"(h) <b>Fauxwood Model Number</b> TW1024QS White TK1024QS Golden Oak <b>Basswood Model Number</b> TD1024QS Mahogany TG1024QS Golden	<b>Shutter Size</b> 39" - 41"(w) x 32"(h) <b>Fauxwood Model Number</b> TW1029QS White TK1029QS Golden Oak
	33 3/4" - 36"	<b>Shutter Size</b> 23" - 25"(w) x 36"(h) <b>Fauxwood Model Number</b> TW1004QS White TK1004QS Golden Oak	<b>Shutter Size</b> 27" - 29"(w) x 36"(h) <b>Fauxwood Model Number</b> TW1010QS White TK1010QS Golden Oak <b>Basswood Model Number</b> TD1010QS Mahogany TG1010QS Golden	<b>Shutter Size</b> 29" - 31"(w) x 36"(h) <b>Fauxwood Model Number</b> TW1015QS White TK1015QS Golden Oak	<b>Shutter Size</b> 31" - 33"(w) x 36"(h) <b>Fauxwood Model Number</b> TW1020QS White TK1020QS Golden Oak <b>Basswood Model Number</b> TD1020QS Mahogany TG1020QS Golden	<b>Shutter Size</b> 35" - 37"(w) x 36"(h) <b>Fauxwood Model Number</b> TW1025QS White TK1025QS Golden Oak <b>Basswood Model Number</b> TD1025QS Mahogany TG1025QS Golden	<b>Shutter Size</b> 39" - 41"(w) x 36"(h) <b>Fauxwood Model Number</b> TW1030QS White TK1030QS Golden Oak