

## Fairfax®

## Essentials Performance Showering Package

#### K-10826-4

#### **Features**

- Performance showering packages offer increased functionality and simplify the ordering process.
- Single lever handle provides on/off activation and temperature setting with a single operation.
- Multifunction showerhead offers wide coverage, therapeutic massage, and soft aerated spray settings.
- Multifunction handshower offers wide soft coverage, soft pulse, and soft aerated spray settings.
- Includes handshower, showerhead, showerarm with diverter, shower hose, slidebar kit, and Rite-Temp valve trim.
- Coordinates with Fairfax® faucets and accessories.
- KOHLER finishes resist corrosion and tarnishing.

#### Installation

- Wall-mount
- Trim only; requires K-304 Rite-Temp pressure-balancing valve (sold separately).

#### **Required Accessories**

K-304/K-P304 Series Rite-Temp® Valves

#### **Optional Accessories**

GP1030932 Deep Roughing-In Kit

#### Components

Product includes:

K-9514 60" Shower Hose

K-9511

K-8524 30" Slidebar

K-12009 Multi-function Showerhead

K-T12021-4 Valve Trim for Rite Temp®

K-349 Slidebar Trim Kit

1055527 Handshower Relaxing



#### Codes/Standards

ASME A112.18.1/CSA B125.1 ASSE 1016 DOE - Energy Policy Act 1992

See website for detailed warranty information.

#### Available Color/Finishes

Color tiles intended for reference only.


| Color | Code | Description             |
|-------|------|-------------------------|
|       | СР   | Polished Chrome         |
|       | BN   | Vibrant® Brushed Nickel |
|       | 2BZ  | Oil-Rubbed Bronze       |



# **KOHLER**, Faucets

## **Fairfax®**

# Essentials Performance Showering Package K-10826-4



#### **Technical Information**

All product dimensions are nominal.

#### Handshower:

Rated maximum flow: 2.5 gal/min (9.5 l/min)

Pressure: 80 psi (5.5 bar)

#### **Showerhead:**

Rated maximum flow: 2.5 gal/min (9.5 l/min)

Pressure: 80 psi (5.5 bar)

#### **Notes**

Install this product according to the installation guide.

Install the Rite-Temp® valve according to the valve installation guide.

