

Quick-start guide


1 Read operator's manual safety section.



2 Charge the battery.



3 Remove the blade sleeve.




4 Fit the battery to the machine.



5 Starting

- Turn on the machine by pressing and holding the start button (>1 sec.) until the green LED is lit.
- Press the front trigger
- Press the latter trigger



This guide is not intended to replace the owner's manual to understand fully how to operate the machine. For customer assistance call: 1-800-487-5951 or visit www.usa.husqvarna.com.

Guía de inicio rápido

1 Lea la sección de seguridad del manual del usuario.

2 Cargue la batería.

3 Quite la tuerca del disco.

4 Ajuste la batería en la máquina.

5 Encienda la máquina

- Mantenga presionado el botón de arranque (más de 1 segundo) hasta que la luz verde LED se encienda para encender la máquina.
- Presione el gatillo delantero
- Presione el gatillo trasero

Esta guía no tiene como objetivo reemplazar el manual del usuario para comprender completamente el funcionamiento de la máquina. Para comunicarse con asistencia al cliente, llame al: 1-800-487-5951 o visite www.usa.husqvarna.com.

Quick-start guide


1 Read operator's manual safety section.



2 Charge the battery.



3 Remove the blade sleeve.




4 Fit the battery to the machine.



5 Starting

- Turn on the machine by pressing and holding the start button (>1 sec.) until the green LED is lit.
- Press the front trigger
- Press the latter trigger



This guide is not intended to replace the owner's manual to understand fully how to operate the machine. For customer assistance call: 1-800-487-5951 or visit www.usa.husqvarna.com.

Guide de démarrage rapide

1 Lire la section sur la sécurité du manuel de l'utilisateur.

2 Charger la batterie.

3 Retirer le manchon de la lame.

4 Placer la batterie dans la machine.

5 Démarrage

- Mettez la machine en marche en appuyant sur le bouton de démarrage et en le maintenant enfoncé (plus d'une seconde) jusqu'à ce que le témoin vert s'allume.
- Appuyez sur le commutateur avant.
- Appuyez sur le commutateur arrière.

Ce guide n'est pas conçu pour remplacer le manuel d'utilisation si vous voulez comprendre parfaitement comment faire fonctionner la machine. Pour joindre le service à la clientèle, appelez le 1 800 487-5951 ou visitez le site www.usa.husqvarna.com.