

Product Fits List

Select Your Brand

Betty Crocker

Model	Medelco Style
BC1732	4 Cup: GL204
BC1733	10 Cup: GL210 (remove pause & serve)
BC1734	4 Cup: GL204
BC1734U12	Cup: GL212 (w/10 cup adaptor)

Black & Decker

Model	Medelco Style
BCM1410B	12 Cup: GL312 (short lid)
CM1010B	12 Cup: GL312
CM1050B	12 Cup: GL312 (short lid)
CM1050W	12 Cup: GL312 (short lid)
CM1650B	12 Cup: GL312
CM2020B	12 Cup: GL312 (short lid)
CM5050	12 Cup: GL312 (tall lid, remove pause & serve)
CM9050	12 Cup: GL312 (remove pause & serve)
DCM18S	n/a single serve
DCM 90WH	10 Cup: GL210 12 Cup: GL200
DCM100B	12 Cup: GL312
DCM400	4 Cup: GL204
DCM500	no fit
DCM580	no fit
DCM675BMT	4 Cup: GL204
DCM900-04	10 Cup: GL210 12 Cup: GL200
DCM901-04	12 Cup: GL212
DCM902	10 Cup: GL210 12 Cup: GL200
DCM903	12 Cup: GL212
DCM1200	12 Cup: GL220

DCM1300	12 Cup: GL220
DCM1330	12 Cup: GL220
DCM1350	12 Cup: GL220
DCM1400	12 Cup: GL312
DCM2000	12 Cup: GL212 , GL312 , GL220 remove pause and serve
DCM2160BC	12 Cup: GL312
DCM2500	GL312
DCM3200	12 Cup: GL312
DE755B	12 Cup: GL312
DE790B	12 Cup: GL312
DLX850	12 Cup: GL312
DLX1050B	12 Cup: GL312 (short lid)
DLX1050W	12 Cup: GL312 (short lid)
GT300	n/a no carafe
HCC100	n/a no carafe
ODC150	10 Cup: GL210
ODC25N	12 Cup: GL200
ODC325	12 Cup: GL200
ODC405	12 Cup: GL200
ODC425	no fit
ODC440	12 Cup: GL200
ODC450	no fit
SDC1	10 Cup: GL210 12 Cup: GL200
SDC1D	12 Cup: GL200
SDC2	10 Cup: GL210 12 Cup: GL200
SDC2A	10 Cup: GL210 12 Cup: GL200
SDC2AG	12 Cup: GL200
SDC3	12 Cup: GL200
SDC3A	12 Cup: GL200
SDC740	12 Cup: GL220
Spacemaker Models	10 Cup: GL210 12 Cup: GL200
SR10	12 Cup: GL200
TCM700	n/a thermal carafe
TCM805	n/a thermal carafe
TCM830	n/a thermal carafe

Braun

Model	Medelco Style
650	12 Cup: GL212
800	12 Cup: GL212

600BUA	12 Cup: GL212
800BGFUA	12 Cup: GL212
800BUA	12 Cup: GL212
4076R	12 Cup: GL212
4092	12 Cup: GL212
4093	12 Cup: GL212
Aromaster	10 Cup: GL210
	12 Cup: GL212
BGABT	12 Cup: GL200
E20	Espresso: EXP100
E25	Espresso: EXP100
E40	Espresso: EXP100
E45	Espresso: EXP100
E600	Espresso: EXP100
E650	Espresso: EXP100
KF10	4 Cup: GL204
	4 Cup: GL204
KF12	Remove Pause and Serve
KF140	no fit
KF32	10 Cup: GL210
KF37	10 Cup: GL210
KF40	10 Cup: GL210
KF400	10 Cup: GL210
KF42	10 Cup: GL210
KF420	10 Cup: GL210
KF45	10 Cup: GL210
KF450	10 Cup: GL210
KF580	no fit
KF60	12 Cup: GL212
KF600	10 Cup: GL210
KF65	12 Cup: GL212
KF650	12 Cup: GL212
KF655	12 Cup: GL212
KF67	12 Cup: GL212
KF675	12 Cup: GL212
KF80	12 Cup: GL212
KF800	10 Cup: GL210

Breville

Model

800ESXL
BDC600XL
ESP8XL

Medelco Style

Espresso: [EXP100](#)
12 Cup Thermal: no fit
Espresso: [EXP100](#)

Bunn

Model	Medelco Style
A10	10 Cup: GL210
B8/B10	10 Cup: GL210
BGABT	12 Cup: GL200
BT10	10 Cup: GL210 12 Cup: GL212
BTX	10 Cup: GL210
BTX	10 Cup: GL210 12 Cup: GL212
BX	10 Cup: GL210
GR Series	10 Cup: GL210 12 Cup: GL200
GRX	10 Cup: GL210 12 Cup: GL220
GT10	10 Cup: GL210 12 Cup: GL212
NHB	
NHBX	10 Cup: GL210
POUR-O-MATIC	10 Cup: GL210 12 Cup: GL200

Capresso

Model	Medelco Style
301	Espresso: EXP100

Cooks

Model	Medelco Style
22005	No Fit

Cuisinart

Model	Medelco Style
CBC-00	12 Cup: GL312
CHW-12	12 Cup: GL312 (tall lid)
DCC-200	12 Cup: GL220
DCC-450	4 Cup: GL204
DCC-500	12 Cup: GL312
DCC-750	12 Cup: GL312 (short lid)

DCC-1000	12 Cup: GL312
DCC-1000BK	12 Cup: GL312
DCC-1100	12 Cup: GL312 (tall lid)
DCC-1100BK	12 Cup: GL312
DCC-1150BK	Thermal Carafe
	12 Cup: GL312 (tall lid)
DCC-1200	12 Cup: GL312 (tall lid)
DCC-1200B	12 Cup: GL312 (tall lid)
DCC-1200BCH	12 Cup: GL312
DCC-1200BW	12 Cup: GL312
DCC-1200W	12 Cup: GL312
DCC-1250SA	12 Cup: GL312
DCC-2200	12 Cup: GL312 (14 cup coffeemaker)
DCC-3000	n/a single serve
DGB-500	12 Cup: GL312
DGB-500BK	12 Cup: GL312
DGB-500R	12 Cup: GL312
DGB-550BK	12 Cup: GL312 (tall lid)
DGB-600BC	12 Cup: GL312
DGB-625BC	12 Cup: GL312 (tall lid)
DGB-650BC	Thermal Carafe
	12 Cup: GL312 (tall lid)
DGB-700BC	12 Cup: GL312
DGB-900BC	Thermal Carafe
	12 Cup: GL312
DTC975	thermal carafe, no fit

DeLonghi

Model

BAR4EE
BCO60
BCO130T
DC56TB
DC59TW
DC60T
DC514T
DCF212T

Medelco Style

Espresso: [EXP100](#)
Espresso: [EXP100](#)
no fit
12 Cup: [GL312](#)
12 Cup: [GL312](#)
12 Cup: [GL312](#) (short lid, remove pause & serve)
12 Cup: [GL312](#) (remove pause & serve)
12 Cup: [GL212](#) (remove pause & serve)

Farberware

Model

103744

Medelco Style

12 Cup: [GL312](#)
(with short lid &

CM3000S adaptor)
12 Cup: [GL312](#) (tall lid; coffee only - won't operate tea infuser)

FCM12SS 12 Cup: [GL312](#)
(short lid; remove pause & serve)

Frigidaire

Model FPDC12D7MS
Medelco Style 12 Cup: [GL312](#) (tall lid)

Gaggia

Model BABY
CLASSIC
COFFEE
ESPRESSO

Medelco Style Espresso: [EXP100](#)
Espresso: [EXP100](#)
Espresso: [EXP100](#)
Espresso: [EXP100](#)

GE

Model 106591
106702
106718
169164
169165
169178
169182
169184
169209
898677
898682
AC120V

Medelco Style 12 Cup: [GL220](#)
12 Cup: [GL220](#)
12 Cup: [GL220](#)
12 Cup: [GL312](#)
12 Cup: [GL312](#)
12 Cup: [GL312](#)
12 Cup: [GL312](#)
12 Cup: [GL312](#)
4 Cup: [GL204](#)
12 Cup: [GL312](#)
5 Cup: Not Tested
12 Cup: [GL312](#) (short lid)
12 Cup: [GL312](#)

Gevalia

Model C-60A
Medelco Style 12 Cup: [GL312](#)

	(tight fit)
CM300	12 Cup: GL312 (short lid, remove pause & serve)
CM500	12 Cup: GL312 (short lid)
CM650	12 Cup: GL312 (remove pause & serve)
XCC-12	12 Cup: GL220 w/adaptor

Hamilton Beach

Model	Medelco Style
40304	12 Cup: GL312 (remove pause & serve)
40515	n/a Party Perk
40729	Espresso: EXP100
40770	12 Cup: GL312
43244C	12 Cup: GL312
43251	12 Cup: GL312
43253	12 Cup: GL312
43254	12 Cup: GL312
43255R	12 Cup: GL312 (tall lid)
43424	no fit
44559	no fit
44601	12 Cup: GL312
45224	n/a thermal carafe
45237	n/a single serve
47214	n/a single serve
47224	n/a single serve
47454	n/a single serve
47665	n/a single serve
48131	4 Cup: GL204
48134	4 Cup: GL204
48464	n/a single serve
48464	n/a single serve
48524	no fit
49121	12 Cup: GL220
49124	12 Cup: GL220
49281	12 Cup: GL220
49284	12 Cup: GL220
49291	12 Cup: GL220
49294	12 Cup: GL220
49444	GL312
49465	12 Cup: GL212

49755	12 Cup: GL312 (short lid, remove pause & serve)
49756	12 Cup: GL312 (short lid, remove pause & serve)
49980	12 Cup: GL312 (tall lid)
49980Z	12 Cup: GL312 (tall lid)
49983	12 Cup: GL312 (tall lid)
49984C	12 Cup: GL312 (tall lid)
Mini Drip HB784	4 Cup: GL204

Jerdon

Model	Medelco Style
CM101W	4 Cup: GL204
CM103B	4 Cup: GL204
CM410WD	4 Cup: GL204 (w/ adaptor)

Kalorik

Model	Medelco Style
25282	12 Cup: GL312 (short lid; remove pause & serve)

Kenmore

Model	Medelco Style
81082	GL204

Keurig

Model	Medelco Style
B40	n/a single serve

Kitchen Selectives

Model	Medelco Style
CM202	12 Cup: GL312 (short lid)

KitchenAid

Model	Medelco Style
KCM055WH3	4 Cup: GL204

KCM110B	12 Cup: GL312 (short lid)
KCM4140B	Not Tested
KCM511	10 Cup: GL210 or GL200 remove pause and serve
KCM5250	n/a thermal carafe
KCM534ER	14 Cup: GL220

Krups

Model

Model	Medelco Style
121	12 Cup: GL212
131	12 Cup: GL212
134	12 Cup: GL220 (remove pause & serve)
137	12 Cup: GL212 (remove pause & serve)
140	10 Cup: GL210
141	12 Cup: GL212
149	10 Cup: GL210
158	12 Cup: GL212
160	12 Cup: GL212
165	12 Cup: GL212
182	12 Cup: GL212
201	12 Cup: GL212
212	12 Cup: GL212
312	12 Cup: GL212
313	12 Cup: GL212
396	10 Cup: 12 Cup: GL212
452	12 Cup: GL220 Remove pause & serve
453	12 Cup: GL212
464	10 Cup: GL210 (base is a bit big)
864	Espresso: EXP100
865	10 Cup: GL210-CP Espresso: EXP100
866	Espresso: EXP100
867	10 Cup: GL210-CP Espresso: EXP100
868	Espresso: EXP100
871	Espresso: EXP100
872	Espresso: EXP100
882	Espresso: EXP100
888	10 Cup: GL210 (Remove Pause & Serve)
933	Espresso: EXP100
963	Espresso: EXP100
967	Espresso: EXP100

968	Espresso: EXP100
971	Espresso: EXP100
972	Espresso: EXP100
985	Espresso: EXP100
	8 Cup: No Fit
987	Espresso: EXP100
993	Espresso: EXP100
1340	12 Cup: GL212
1350	12 Cup: GL212
1370	12 Cup: GL212
FME2-11	12 Cup: GL312
FME2-14	12 Cup: GL312 (short lid)
FME4	12 Cup: GL312 (short lid)
FME4-14	12 Cup: GL312
FMF 5	12 Cup: GL312
FMF 5-14	12 Cup: GL312
FND111	Espresso: EXP100
KF740	12 Cup: GL312 (short lid)
KM406	12 Cup: GL212
KM730	12 Cup: GL312 (short lid)
KM1000	12 Cup: GL212
KM4055	12 Cup: GL212
KT720D50	Thermal Carafe - no fit
T027	Espresso: EXP100
XP 1500	Combo: EXP100/GL212
XP2070	Espresso: EXP100
XP4030	Espresso: EXP100

Melitta

Model	Medelco Style
ACM10	10 Cup: GL210 12 Cup: GL212
ACM10A4	10 Cup: GL210
ACM10B4	10 Cup: GL210
ACM10E4	10 Cup: GL210
ACM10G	12 Cup: GL200
ACM10G4	10 Cup: GL210
ACM10H	10 Cup: GL210
ACM10M/4	10 Cup: GL210
ACO12T	12 Cup: GL200 12 Cup: GL220

ACP12	12 Cup: GL200
DPB	12 Cup: GL220
ME12DSBCAN	GL312
ME2DMCBT	GL312
ME2TMB	n/a no carafe
MEFB1	n/a single serve
MEMB1B	12 Cup: GL312
	no fit

Moulinex

Model	Medelco Style
85	Espresso: EXP100
86	Espresso: EXP100
985	Espresso: EXP100
W50	Espresso: EXP100

Mr. Coffee

Model	Medelco Style
AD10	10 Cup: GL210
AD12	12 Cup: GL220
AR10	12 Cup: GL220
AR11	12 Cup: GL220
AR4	4 Cup: GL204
ARX10	12 Cup: GL220
ARX20	12 Cup: GL220
ARX23	12 Cup: GL220
BL110	12 Cup: GL220
BL113	12 Cup: GL220
BL213	4 Cup: GL204
BL4	4 Cup: GL204
BL5	4 Cup: GL204
BL6	4 Cup: GL204
BLX210	12 Cup: GL220
BLX213	12 Cup: GL220
BVMC-CHX23	no fit
BVMC-EJX33	12 Cup: GL312
BVMC-EJX36	12 Cup: GL312
BVMC-EJX37	12 Cup: GL312
BVMC-LMX43	12 Cup: GL312
BVMC-PSTX91	10 Cup Thermal Carafe: no fit
BVMC-PSTX95GTF	10 Cup Thermal Carafe: no fit
BVMC-SJX33GT	12 Cup: GL312 (short lid)
BVMC-SJX36GTWM	12 Cup: GL312 (short lid)

BVMC-SJX39	12 Cup: GL312 (short lid)
BVMC-VMX37WM	12 Cup: GL312
BVX23	12 Cup: GL312
CBS700	10 Cup: GL210
CBS900	10 Cup: GL210
CBTU45	n/a party perk
CG12	12 Cup: GL312 (short lid; tight fit)
CG13	12 Cup: GL312 (short lid; tight fit)
CGX20	12 Cup: GL312 (short lid; tight fit)
CGX23	12 Cup: GL312 (short lid; tight fit)
CHX23	12 Cup: GL312 (short lid)
CM10	10 Cup: GL210
	12 Cup: GL200
CMX1000	10 Cup: GL210
CMX15	10 Cup: GL210
CMX20	10 Cup: GL210
CMX400	12 Cup: GL200
CMX55	12 Cup: GL200
D - Series	4 Cup: GL204
DR13	12 Cup: GL312
DR4	4 Cup: GL204
DRTX84	n/a thermal carafe
DRX20	12 Cup: GL312
DRX23	12 Cup: GL312
DRX5	4 Cup: GL204
	10 Cup: GL210
DSP10	12 Cup: GL200
	12 Cup: GL220
DW12	
DW13	12 Cup: GL312
DWX23	12 Cup: GL312
EC5	no fit
ECM10	Espresso: EXP100
ECM13	Espresso: EXP100
ECM15	Espresso: EXP100
ECM150	Espresso: EXP100
ECM2	Espresso: EXP100
ECM20-23	Espresso: EXP100
ECM3	Espresso: EXP100
ECM7	Espresso: EXP100
ECM8	Espresso: EXP100
ECM9	Espresso: EXP100
ECM91	Espresso: EXP100
ECMP50	Espresso: EXP100
Elite Models	12 Cup: GL220
ES10	12 Cup: GL212

ES11	12 Cup: GL212
ESX10	12 Cup: GL212
ESX11	12 Cup: GL212
FTTX85	12 Cup: GL312
FTTX95	12 Cup: GL312
FTX20	12 Cup: GL312 (short lid)
FTX21	12 Cup: GL312 (short lid)
FTX23	12 Cup: GL312 (short lid)
FTX24	12 Cup: GL312 (short lid)
FTX25	12 Cup: GL312 (short lid)
FTX26	12 Cup: GL312 (short lid)
FTX27	12 Cup: GL312 (short lid)
FTX29	12 Cup: GL312 (short lid)
FTX40	12 Cup: GL312 (short lid)
FTX41	12 Cup: GL312 (short lid)
FTX43	12 Cup: GL312 (short lid)
FTX44	12 Cup: GL312 (short lid)
FTX45	12 Cup: GL312 (short lid)
FTX46	12 Cup: GL312 (short lid)
FTX47	12 Cup: GL312 (short lid)
FTX49	12 Cup: GL312 (short lid)
FTXSS23GTF	12 Cup: GL312 (short lid)
FTXSS43GTF	12 Cup: GL312 (short lid)
FX25	12 Cup: GL312
GBX12	12 Cup: GL220
GBX20	12 Cup: GL212
GBX23	12 Cup: GL312
HCB50	4 Cup: GL204
HCB50X	4 Cup: GL204
HCB63	4 Cup: GL204
ID40	4 Cup: GL204
IDS	4 Cup: GL204
IDS12	10 Cup: GL210
ISS12	12 Cup: GL312
ISS13	12 Cup: GL312
ISTX95	12 Cup: GL312
ISX12	12 Cup: GL312
ISX20	12 Cup: GL312
ISX23	12 Cup: GL312
ISX23BP	12 Cup: GL312
ISX26	12 Cup: GL312
ISX3	12 Cup: GL312
ISX40	12 Cup: GL312
ISX43	12 Cup: GL312
ISX46	12 Cup: GL312
JR4	4 Cup: GL204

JR40	4 Cup: GL204
JR44	4 Cup: GL204
JWX23WM	12 Cup: GL312 (short lid)
JWX31BP	12 Cup: GL312 (short lid)
MC1212	10 Cup: GL210
MCS201	10 Cup: GL210
MCS23	10 Cup: GL210
MP12	12 Cup: GL220
MRX33	12 Cup: GL312
N - Series	4 Cup: GL204
NC12	12 Cup: GL212
NC13	12 Cup: GL212
NCS12	12 Cup: GL212
NCS13	12 Cup: GL212
NCX20	12 Cup: GL212
NCX23	12 Cup: GL212
NL5GTF	no fit
NLX5	4 Cup: GL204
PD123	12 Cup: GL220
PL12	12 Cup: GL212
PL13	12 Cup: GL212
PLX20	12 Cup: GL212
PLX20BP-2	12 Cup: GL212
PLX23	12 Cup: GL212
PLX23BP-2	12 Cup: GL212
PLX26BP-2	12 Cup: GL212
PR12A	12 Cup: GL220
PR13	12 Cup: GL220
PR14	12 Cup: GL220
PR15	12 Cup: GL220
PR16	12 Cup: GL220
PR17	12 Cup: GL220
PR4	4 Cup: GL204
PR6	4 Cup: GL204
PR6-D	4 Cup: GL204
PRX20	12 Cup: GL220
PRX23	12 Cup: GL220
PRX30	12 Cup: GL220
PRX30D	12 Cup: GL220
PRX33	12 Cup: GL220
RMX23	12 Cup: GL312
SK12	12 Cup: GL312
SKX20	12 Cup: GL312
SKX23	12 Cup: GL312
SRX20	12 Cup: GL312 (remove pause & serve)
SSP23	n/a single serve

TF6	5 Cup: Not Tested
TF12	12 Cup: GL312
TF13	12 Cup: GL312
TF4	no fit
TFS12	12 Cup: GL212
TFTX85	n/a thermal carafe
TFX Series	12 Cup: GL312
TR4	4 Cup: GL204
TR40	4 Cup: GL204
TRX23	12 Cup: GL312
TXX23	12 Cup: GL212
UNX20	12 Cup: GL220
UNX23	12 Cup: GL212
	12 Cup: GL220
UR12	12 Cup: GL220
UR13	12 Cup: GL220
UR17	12 Cup: GL220
	12 Cup: GL212
URX20	
	12 Cup: GL220
URX23	12 Cup: GL220
URX30	12 Cup: GL220
URX33	12 Cup: GL212
	12 Cup: GL220
URX37	12 Cup: GL220
US001	10 Cup: GL210
	12 Cup: GL200
UTC100	10 Cup: GL210
	12 Cup: GL200
UTC300	12 Cup: GL200
UTC303	10 Cup: GL210
VB12	12 Cup: GL312
VB13	12 Cup: GL312
VBX20	12 Cup: GL312
VBX23	12 Cup: GL312
ZGX20	12 Cup: GL312

Mr. Coffee Concepts

Model	Medelco Style
HCB50	4 Cup: GL204
HCB50X	4 Cup: GL204
HCB63	4 Cup: GL204
JR40	4 Cup: GL204

Norelco

Model	Medelco Style
CT162	10 Cup: GL210 12 Cup: GL200
CT663	12 Cup: GL200 10 Cup: GL210
CT663eB	12 Cup: GL200 12 Cup: GL220
Express HB5122	4 Cup: GL204
HB5124	4 Cup: GL204
HB5183	12 Cup: GL200
HB5184	12 Cup: GL200
HB5185	12 Cup: GL200 12 Cup: GL220
HB5186	12 Cup: GL200
HB5186-C	12 Cup: GL200
HB5187	12 Cup: GL200

Oster

Model	Medelco Style
3306-33	12 Cup: GL312 (Pour spout in back)
3309-33	12 Cup: GL312
7995-33	12 Cup: GL312
A415	12 Cup: GL200
A415	12 Cup: GL200

Phillips

Model	Medelco Style
HD Sensio	n/a no carafe
HD5275	12 Cup: GL220

Proctor Silex

Model	Medelco Style
40104	4 Cup: GL204
40105	4 Cup: GL204
40188	4 Cup: GL204
41331	12 Cup: GL220
41334	12 Cup: GL220
41461	12 Cup: GL220

41464	12 Cup: GL220
42101	12 Cup: GL220
42114	n/a single serve
42301	12 Cup: GL220
42304	12 Cup: GL220
42331	12 Cup: GL220
42334	12 Cup: GL220
42371	12 Cup: GL220
42461	12 Cup: GL220
42464	12 Cup: GL220
43501	12 Cup: GL212
43531	12 Cup: GL220
43571	12 Cup: GL220
43574	12 Cup: GL220
44301	n/a single serve
44401	10 Cup: GL210
46101	12 Cup: GL220
46104	12 Cup: GL220
46261	12 Cup: GL220
46385	12 Cup: GL220
46801	Not Tested
46888	12 Cup: GL220
48134	4 Cup: GL204
48503	12 Cup: GL220
48521	12 Cup: GL220
48521RY	10 Cup: GL210 (remove pause & serve)
48524	12 Cup: GL220
48561	12 Cup: GL220
48571	12 Cup: GL220
48574	No Fit
92000	4 Cup: GL204
607HB	12 Cup: GL212
A6	12 Cup: GL200
A100	10 Cup: GL210
A301	10 Cup: GL210
A302	10 Cup: GL210
A306	10 Cup: GL210
A415	12 Cup: GL200
A415AL	10 Cup: GL210 12 Cup: GL200
A416	10 Cup: GL210 12 Cup: GL200
A600	10 Cup: GL210 12 Cup: GL200
A6078	10 Cup: GL210 12 Cup: GL200

	12 Cup: GL220
	10 Cup: GL210
A607A	12 Cup: GL200
	12 Cup: GL220
	10 Cup: GL210
A6089	12 Cup: GL200
	12 Cup: GL220
A617	10 Cup: GL210
	12 Cup: GL200
A625	10 Cup: GL210
	12 Cup: GL200
A635	10 Cup: GL210
	12 Cup: GL200
A6378	12 Cup: GL220
A8004	4 Cup: GL204
A8335W	12 Cup: GL220
A8704	4 Cup: GL204
A8757	4 Cup: GL204
C40107	4 Cup: GL204
C40207	4 Cup: GL204
D40101	4 Cup: GL204

Regal

Model	Medelco Style
7567	12 Cup: GL200

Rival

Model	Medelco Style
PIL-HC08104	12 Cup: GL312
PIL-HC091121	12 Cup: GL312 (short lid)
PIL-HC10106	12 Cup: GL312

Sensio

Model	Medelco Style
OM4225-A	12 Cup: GL312 (short lid)

Sunbeam

Model	Medelco Style
3279	4 Cup: GL204
3280	4 Cup: GL204

3289	4 Cup: GL204
6385	12 Cup: GL220
6000 Series	12 Cup: GL312
BVSB-TGX23	12 Cup: GL212
HDX23	12 Cup: GL312
HDX25	12 Cup: GL312
HDX33	12 Cup: GL312 (tall lid)

Toastmaster

Model	Medelco Style
TCM10PW	untested
TCM12PW	12 Cup: GL212 (w/ 10 cup adaptor)
TCM12W	12 Cup: GL212 (w/ 10 cup adaptor)

West Bend

Model	Medelco Style
55108	12 Cup: GL220 remove pause and serve
55120	12 Cup: GL220 remove pause and serve
56630	12 Cup: GL220
56690	12 Cup: GL220
56860	n/a thermal carafe
56870	no fit
56880	no fit