

## **Product Information**

| Applicable product:  |           |        |
|--|-----------|--------|
| Kathryn <sub>®</sub> fireclay console tabletop with 10" (254 mm) faucet drilling                 |           | K-3020 |
| Required accessories:  |           |        |
| Kathryn <sub>®</sub> 17" (432 mm) x 13" (330 mm) under-mount bathroom sink with glazed underside | K-2330-G  |        |
| Kathryn <sub>®</sub> octagonal brass legs <b>OR</b>  | K-6839    |        |
| Kathryn <sub>®</sub> octagonal fireclay/French gold brass legs <b>OR</b>                         | K-2317-AF |        |
| Kathryn <sub>®</sub> octagonal fireclay/brushed nickel brass legs <b>OR</b>                      | K-2317-BN |        |
| Kathryn <sub>®</sub> octagonal fireclay/polished chrome legs <b>OR</b>                           | K-2317-CP |        |
| Kathryn <sub>®</sub> octagonal fireclay/polished nickel legs <b>OR</b>                           | K-2317-SN |        |
| Kathryn <sub>®</sub> square fireclay legs  | K-2318    |        |

## **Installation Notes**

Install this product according to the installation guide.

Product is installed with 1/2'' (13 mm) gap between wall and console table.

Frame is included with K-3020.



