

# 88 5411 13

## Cabin Creek


### Media Tower

#### IMPORTANT NOTE


Carefully remove all the parts from the carton and put them individually on a soft cloth to prevent scratches or other damages occurring to the parts.

We have taken great care in the design of this product and request that you carefully and strictly follow our assembly instructions to ensure a completed product as it was designed.


*Home Styles*




## Part List




**A.  
Cabinet**  
1 pc.




**B.  
Stretcher**  
2 pcs.




**C.  
Side Frame**  
2 pcs.




**D.  
Shelf**  
2 pcs.



**E.  
Shelf**  
2 pcs.



**F.  
Side Frame**  
2 pcs.



**G.  
Back Frame**  
1 pc.



**H.  
Stretcher**  
1 pc.



**I.  
Top**  
1 pc.

## Hardware List




**Hex Wrench**  
1 pc.




**Head Cap Bolt**  
56 pcs. (+1 extra)



**Spring Washer**  
60 pcs. (+1 extra)



**Drawer Stop**  
1 pc.



**Tapered  
Head Cap Bolt**  
4 pcs. (+1 extra)



**Small  
Hex Wrench**  
1 pc.



**Head Cap Bolt (long)**  
4 pcs. (+1 extra)




**Flat Washer**  
56 pcs. (+1 extra)



**Big Flat Washer**  
4 pcs. (+1 extra)



**Wood Screw**  
5 pcs. (+1 extra)



**Steel Plate  
Connector**  
2 pcs. (+1 extra)


**Tools required for assembly :** Phillips screwdriver

**Tools recommended for assembly :** Level

**Home Styles Consumer Assistance:** [www.homestyles-furniture.com](http://www.homestyles-furniture.com),  
[servicedesk@homestyles-furniture.com](mailto:servicedesk@homestyles-furniture.com), 888-680-7460, 877-831-0319

## IMPORTANT


- \* Do not tighten up all the screws until each part is properly assembled.
- \* You should keep Hex Wrench in a safe place as you may need to tighten up the Head Cap Bolts in the future.
- \* Use a soft cloth between these parts and the floor.
- \* After assembly, item must be level to work properly. Use the included adjustable levelers to level.



## STEP 1


Loosen, only halfway, the bolts located in bottom side of the back rail of Shelves (C). (see Figure 1)

Attach Stretchers (B) and Shelves (D) to Side Frames (C) with Head Cap Bolts, Spring Washers and Flat Washers. (see Figure 2)



Attach Side Frame (C) to unit with Head Cap Bolts, Spring Washers and Flat Washers.


Re-tighten the bolts located in bottom side of the back rail Shelves (C).



## STEP 2

Remove the drawer, then place Cabinet (A) upside down on a soft cloth. (see Figure 3)

Attach unit onto Cabinet (A) with Wood Screws, Head Cap Bolts, Spring Washers and Big Flat Washers.



## STEP 3

Remove the Pull Handle that is installed on the inside of the drawer and re-install it on the outside of the drawer. (see Figure 4)

Turn the unit over to its' upright position.

Attach Drawer Stop with Wood Screw into the pre-drilled holes inside the opening of the unit. (see Figure 5)

Slide the drawer into position.




Figure 4






Figure 5

Wood Screw  
Drawer Stop



Flat Washer

Spring Washer

Head Cap Bolt


## STEP 4

Attach Stretchers (H) Back Frame (G) and Shelves (E) to Side Frames (F) with Head Cap Bolts, Spring Washers and Flat Washers. (See figure 1)

Attach Side Frame (F) to unit with Head Cap Bolts, Spring Washers and Flat Washers.

## STEP 5

Attach Top (I) to unit with Head Cap Bolts (long), Spring Washers and Flat Washers.



## STEP 5

Place upper unit onto base unit.

Attach Steel Plate Connectors to unit with Tapered Head Cap Bolts and Wood Screws.

To level the unit, adjust the adjustable levelers on the bottom of unit. (see Figure 6)





Figure 6