

4137

DROP LEAF PEDESTAL BASE TABLE

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



www.coastercompany.com

REVISION 0 : 07/24/2006 REVISION 1 : 12/19/2011

REVISION 2: 09/20/2014

ASSEMBLY TIPS:

- 1. Remove hardware from plastic bag and sort by size.
- 2. Please check to see that all hardware and part are present prior to start of assembly.
- 3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



Warning!

- **1.** Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.

PARTS IDENTIFICATION:

AN	TABLE TOP	1PC
BN1	PEDESTAL LEG WITH HOLES	1PC
BN2	PEDESTAL LEG WITH INSERT	1PC
CN	PEDESTAL BASE	1PC
DN	MOUNTING BAR	2PCS

HARDWARE IDENTIFICATION:

1		ALLEN WRENCH	1PC
2		LONG BOLT	2PCS
3		SHORT BOLT	4PCS
4		LOCK WASHER	4PCS
5		FLAT WASHER	4PCS
6		WOOD PLUG	2PCS
7	→mmm>	PAN HEAD SCREW	8PCS
8		LEVELER	4PCS


NOTE: PHILLIPS HEAD SCREW DRIVER IS REQUIRED IN THE ASSEMBLY PROCESS. HOWEVER, MANUFACTURER DOES NOT PROVIDE THIS ITEM.



STEP 1


1.1 Align and fasten pedestal base (CN) to pedestal legs (BN1 & BN2) using long bolt (2) and tighten with Allen wrench (1).

1.2 Insert wood plug (6) to cover the open hole of pedestal



STEP 2


Align and fasten mounting bar (DN) to the top of pedestal base (CN) and leg (BN1 & BN2) using short bolt (3), lock washer (4) and flat washer (5) and tighten with Allen wrench



STEP 3

3.1 Place table top (AN) upside down on soft surface. Align and position mounting bar (DN) onto the marking at the bottom of table top (AN). Then fasten using pan head screw (7) and tighten with Phillips head screw driver (Not Included).

3.2 Screw in leveler (8) to the bottom of pedestal base (CN) and leg (BN1 &BN2).



STEP 4

Flip table over using two people to lift and flip this table. Adjust leveler to touch the floor.

