

Preparation: Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.


Fixture can only be mounted in the direction indicated on page 2.

Δ Warnings and Cautions

Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.

These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation.

Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal. Do not subject glass parts to any shock while in operation or shattering may result.



HOW TO REPLACE GLASS PANELS

HOW TO REPLACE LED MODULE

A. Unlock Allen Screws on the Fixture Hood. Separate Quick

fixture.

Connector and then remove Cage with Glass Panels from the

- A. Unlock Allen Screws on the Fixture Hood. Separate Quick Connector and then remove Cage with Glass Panels from the fixture.
- B. Unscrew Screws from the Cage and remove LED Module and Heat
- B. Unscrew Screws from the Cage and remove LED Module and Heat Sink. Sink, Glass Holders. C. Unscrew Lock Screws on the LED Module. Replace the LED Module Allen Screw Replace Glass Panels from with the replacement. the Cage and then re-install **Fixture Hood** Glass Holders, LED Module Pass Lock Screws Allen Screw and Heat Sink . Secure with through the Quick **Fixture Hood** removed Screws. Connector replacement LED T C. Connect Quick Connectors. Module, the Heat Sinks Screw Quick Attach Cage with Glass as shown and thread Hex Connector Panels back onto the Fixture LED Module Hex Nuts onto Lock Nut and Heat Sink Screws to secure them Hood and secure with Allen together. Hand tighten Screws. until snug. Upper Screw TT D. Pass the Quick Glass Holder Heat Sink Heat Sink Connector from the LED Module through the hole LED Module İİ on the Heat Sink. Lock Screw E. Re-install LED Module Glass Panel and Heat Sink onto the top edge of the Cage. Cage with Secure with Screws. **Glass Panels** Connect Quick Connectors. Attach Cage with Glass Panels Figure 6 back onto the Fixture Cage Hood and secure with Allen Screws. Figure 7 SNNL8408PN SNNL8408K 4.5 FINISH: MYSTIC BLACK FINISH: PALLADIAN BRONZE яłh s⊧₿ a 5 8 Fixture can only be 6.5" mounted in the direction indicated 12.5' (1)NO. PART NUMBER REPLACEMENT PART REQ 4 1 G3728PA **GLASS PANEL** NOTE: ALL DIMENSIONS ARE ROUNDED UP TO THE NEAREST 1/4" Thank you for purchasing a Quoizel product. Need assistance with parts or assembly? Call Quoizel customer service at 1-631-273-2700 or visit us on-line at www.quoizel.com July2015 © 2015 Quoizel Inc.