


ASSEMBLY AND INSTALLATION INSTRUCTIONS

P0021 / P0026

WARNING: BE SURE TO SHUT OFF POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE INSTALLING OR SERVICING THIS FIXTURE.

**NOTE: 1. Before installing, consult local electrical codes for wiring and grounding requirements.
2. READ AND SAVE THESE INSTRUCTIONS.**

Contents of Spare Parts:



1. Thread two screws to the mounting strap, and secure with two lock nuts. Adjust the length of the screws if necessary.
2. Attach the mounting strap to outlet box by using two mounting screws.
3. Rod connections:
 - a. Thread the fixture wire from the fixture through the lower rod, and then secure the lower rod onto fixture using the nipple.
 - b. Thread the fixture wire through the middle rod, and then secure the middle rod onto the lower rod using the nipple.
 - c. Thread the fixture wire through the upper rod, and then secure the upper rod onto the middle rod using the nipple.

The height can be adjustable to 30", 42", 54", 66" or 78" by using the rods.

4. Thread the fixture wire through the canopy kit, then secure the rod assembly to the set nipple of the canopy kit.
5. Pull out the outlet wires and the house grounding wire from the outlet box. Make wire connections using the wire nuts:
 - The black wire from fixture to the black wire from power source.
 - The white wire from fixture to the white wire from power source.
 - Attach the fixture grounding wire to the mounting strap with the green grounding screw. Then connect it to the house grounding wire with the wire nut.
 Carefully put the wires back into the outlet box.

6. Attach the canopy to the mounting strap by inserting the screws, and secure it with two ball nuts.
7. Attach the glass shades to the glass holders, then secure them with the spacers and socket rings.
8. Install bulbs (not included). See relamping label at socket area or packaging for maximum allowed wattage.
9. Turn on the power at the main fuse or circuit breaker box.

