## "Antebellum" Media Fireplace Mantle


FA930500TX- Black-Walnut 2 Finishing FA930600TX- Antique White Finishing FA930800TX- Natural Oak Finishing

**Assembly Instructions** 




For assistance with assembly contact:
Southern Enterprises Inc.
Customer Service 1-800-633-5096
service@seidal.com
www.seidal.com

PO:



## "Antebellum" Media Fireplace Mantle Parts List

Please review all parts and hardware before disposing of any packaging. Call Customer Service if missing hardware. Do not return to store/retailer. Using hardware that is too long will cause damage. Before beginning assembly, separate each type of hardware. Carefully study the hardware diagrams below. You may receive extra hardware with your unit



#### "Antebellum" Media Fireplace Mantle Parts List

Please review all parts and hardware before disposing of any packaging. Call Customer Service if missing hardware. Do not return to store/retailer. Using hardware that is too long will cause damage. Before beginning assembly, separate each type of hardware. Carefully study the hardware diagrams below. You may receive extra hardware with your unit


(1) Quant of 2:	(2) Quantity of 3	(3) Quantity of 20	(4) Quantity of 20
8mm x 30 mm Wood Dowel	3/16" x 1" Bolt	Cam Lock Bolt	Cam Lock
(5) Quant of 2	(6) Quantity of 4	(7) Quantity of 42	(8) Quantity of 2
	<	<	
Magnet	3.5mm x 15mm Screw For Magnet	3.5mm x 12 mm Screw For Back	Wood Knob
(9) Quant of 2	ty (10) Quantity of 8	(11) Quantity of 2	(12) Quantity of 4
(C)		!!!!!!!!!!<b !	O ZZZ
5/32" x 22mm Bolt For Knob	Metal Pin	8mm x 25mm Screw For Wood Holder	Bracket
(13) Quant	(14) Quantity		(4.6) Oughtitus
of 4	of 4	(15) Quantity of 4	(16) Quantity of 2
	· • ( = · /		


#### **Care and Cleaning Instructions:**

Before using, wipe with a clean, dry cloth. Periodically apply furniture wax to renew the finish. Avoid rubbing or scratching the surface with rough or abrasive objects.

For replacement parts or questions, please call Customer Service at 1-800-633-5096. Do not return product to store. Please call manufacturer for assistance, questions or parts.


Assembly Tool Required No. 2 Phillips Screwdriver (Not Included)






Assembly Instructions:
Wood may scratch easily. Be careful
when assembling. Do not scratch.


- Step 1. Unpack and lay parts on clean, padded surface like carpet or blanket. Check that you have all parts indicated on the front page.
- Step 2. Put the Bottom Base(A), Side Panels(B,C), Top Panel(E) and Horizontal Fixed Shelf(D) on the soft working surface. Then attach Cam Lock Bolt(3) to them.
- Step 3. Attach Magnet(5) to Horizontal Fixed Shelf(D) with Screw for Magnet(6).






- Step 1. Insert the Wood Dowels(1) into predrilled holes in Middle Panels(F,G).
- Step 2. Attach Middle Panels(F,G) to the Bottom Base(A) with Cam Lock(4)







Step 2. Attach Top Stretcher(H) to Middle Panels(F,G)



Step 1. Insert the Wood Dowels(1) into predrilled holes in Middle Panels(F,G) and Top Stretcher(H).

Step 2. Attach Horizontal Fixed Shelf(D)
to the Middle Panels(F,G) and Top
Stretcher(H) with Bolt(2) and
Cam Lock(4).






Step 1. Insert the Wood Dowels(1) into predrilled holes in Horizontal Fixed Shelf(D) and bottom of Side Panels(B,C).

Step 2. Attach Side Panels(B,C) to the Bottom Base(A) and Horizontal Fixed Shelf(D) with Cam Lock(4).






Step 1. Insert the Wood Dowels(1) into predrilled holes in Side Panels(B,C).

Step 2. Attach Top Panel(E) to the Side Panels(B,C) with Cam Lock(4).




Figure 6



Step 1. Attach Metal Knob(8) to Doors
(I,J) with Bolt For Metal Knob(9).

Step 2. Attach Optional Center Support(P) between the Top Panel(E) and Horizontal Fixed Shelf(D).






Figure 10


(11)

Quantity

of 2


Screw For Wood Holder

8mm x 25mm



- Step 1. Attach Bracket(12) to the Top Panel(E) with Screw For Bracket(13).
- Step 2. Drill 1/4 pilot holes in near proximity of the Bracket(12) attached to the Top Panel(E) and tap the Plastic Anchor(14) into wall.
- Step 3. Fasten Bracket(12) using Screw For Wall(15) into the Plastic Anchor(14).

(12)	02230	Quantity of 4	
	Bracket		
(13)		Quantity of 4	
	3.5mm x 15 mn	า ี	
	Screw For Bracket		
(14)		Quantity of 4	
	Plastic Anchor		
(15)	7mm x 38 mm	Quantity of 4	
	Screw For Wall		



Step 1. Move this item to the fastened wall Bracket(12) and tie in both Bracket(12) with Plastic Chain(16) as shown in diagram.



### Parts Replacement Form

Customer Information					
Name					
Address					
•					
City/State/Zip Code					
Phone Number					
Please indicate where you purchased this item: Store/Website/Catalog					
Please indicate color/size/style number:					
Style No Part	s Letter	Parts Description	Quantity Needed		
		Parts Description	Quantity Needed		

Please immediately examine this product carefully. Any request for missing parts or damage replacement must be received within 90 days of your receipt of the product. Replacement, if available, will be honored within this time frame. Parts will not be available for items arriving fully assembled. We do not recommend modifying product(s) and we are not responsible for any damages due to product modification(s). If damages or missing parts are not reported within 90 days of your receipt, we are under no obligation to provide parts or replacement merchandise.

Please contact Southern Enterprises at 800-633-5096 or in Dallas 972-869-0111/ 9am 4pm Mon-Fri Central time if you have product issues or email us at service@seidal.com. Please ask for customer service representative for issues involving damages or replacement parts. Please ask for technical assistance representative for any issues with product and assembly/construction.

Please contact the retailer that you purchased from for returns.



Customer Service 1-800-633-5096
<a href="mailto:service@seidal.com">service@seidal.com</a>
Southern Enterprises, Inc.
600 Freeport Parkway, Suite 200
Coppell, Texas, 75019



The top shelf is intended for a flat screen television with a maximum overall width of 46" and supports up to 85 lb.

The top shelf is NOT INTENDED for tube televisions.

Each center shelf should not be loaded with more than 20 lb. Each side shelf should not be loaded with more than 15 lb.

DO NOT EXCEED RECOMMENDED LOAD. Use with products heavier than the maximum sizes and weights indicated may result in instability causing possible injury.

This unit contains a permanent warning sticker located on under side of top shelf or inside drawer.

Do not allow children under 16 years to move the cart.

Model: FA930500TX & FA930600TX & FA930800TX "Antebellum" Media Fireplace Mantle Southern Enterprises, Inc 600 Freeport Parkway, Suite 200 Coppell, Texas, 75019

Manufacture Date: 08/25/2011