

Providence Convertible Fireplace Tower

FA980700TX – New Mahogany


FA980800TX – Antique White

Assembly Instructions



Southern
ENTERPRISES

















For assistance with assembly, contact:
Southern Enterprises Inc.
Customer Service 1-800-633-5096
service@seidal.com
www.seidal.com
















Providence Convertible Fireplace Tower

Parts List

Please check packaging for all parts and hardware before discarding. Unpack and lay parts on clean, padded surface like carpet or blanket. Check that you have all parts indicated. Call customer service if hardware is missing. Before beginning assembly, carefully study the diagrams below and sort your hardware according to the pictures. Using the incorrect hardware will cause damage.

A  Wood Dowel Quantity of 16 (Ø5/16"×1-3/16"L)	B  Bolt Quantity of 12 (Φ1/4"×1"L)
C  Flat Washer Quantity Of 12	D  Flat Head Screw Quantity Of 6 (Φ3*20mmL)
E  Round Head Screw Quantity Of 16 (Φ3*12mmL)	F  Flat Head Screw Quantity Of 8 (Φ3*12mmL)
G  Firebox Quantity Of 1 (shipped in a separate carton)	H  Magnet Quantity Of 1
I  Flat Head Screw Quantity Of 2 (Φ5/16"×7/8"L)	J  Round Head Screw for Magnet Quantity Of 2 (Φ3mm*13.5mmL)
K  Screw Quantity Of 4 (Φ7MM*5/8"L)	L  Bracket Quantity Of 4
M  Screw Quantity Of 4 (Φ7MM*1"L)	N  Wall Anchor Quantity Of 4
O  Plastic Strap Quantity Of 2	1  Front Top Panel Quantity Of 1

2  Back Top Panel Quantity Of 2	3  Left Frame Quantity Of 1
4  Right Frame Quantity Of 1	5  Middle Shelf Panel Quantity Of 1
6  Left Door Quantity Of 1	7  Right Door Quantity Of 1
8  Middle Shelf Panel Quantity Of 1	9  Bottom Panel Quantity Of 1
10  Leg Quantity Of 4	11  Leg Quantity Of 4
12  Back Panel Quantity Of 1	13  Wood Holder Quantity Of 1
Care and Cleaning Instructions: Before using, wipe with a clean, dry cloth. Periodically apply furniture wax to renew the finish. Avoid rubbing or scratching the surface with rough or abrasive objects.	Call Customer Service at 1-800-633-5096, please call manufacturer for assistance, questions or parts.
Assembly Tool Required No.2 Phillips Screwdriver (Not Included)	

Providence Convertible Fireplace Tower

Assembly Instructions




Figure 1

Turn the middle shelf panel (5) over and use 2pcs round head screws (J) to connect magnet (H) to middle shelf panel (5) with Phillips screwdriver.




Figure 2

Attach middle shelf panels (5) and (8) to the left frame (3) by inserting wood dowels (A). Repeat step with right frame (4) and middle shelf panels (5) and (8) for assembly.

Use 8pcs bolts (B) through 8pcs flat washers (C) to connect the middle shelf panels (5) and (8) to both side panels (3) and (4).

Tighten bolts (B) with Phillips screwdriver.

Providence Convertible Fireplace Tower

Assembly Instructions




Figure 3

Attach legs (10) to assembled unit by rotating the legs (10) clockwise tightly with hand.




Figure 4

Use legs (11) through bottom panel (9) to connect bottom panel (9) to the four legs (10) by rotating legs (11) clockwise tightly with hand.

Providence Convertible Fireplace Tower

Assembly Instructions




Figure 5

Use 6pcs flat head screws (D) to connect front top panel (1) to back top panel (2) via attached hinges.

Tighten flat head screws (D) with Phillips screwdriver.





Figure 6

Attach top panels (1) and (2) to assembled unit by inserting 4pcs wood dowels (A).


Use 4pcs bolts (B) through 4pcs flat washers (C) to connect top panel (1) and (2) to assembled unit.

Tighten bolts (B) with Phillips screwdriver.



Attach the back panel (12) onto the back of the unit by using 16pcs screws (E).

Figure 7



Use 8pcs screws (F) to connect door panels (6) and (7) to assembled unit with Phillips screwdriver.

Figure 8

Providence Convertible Fireplace Tower

Assembly Instructions




Figure 9

Place firebox (G) into the back of the unit.




Figure 10

Attach wood holder (13) by inserting 2pcs flat head screws (I) into corresponding predrilled holes and tighten with Phillips screwdriver.

Providence Convertible Fireplace Tower

Assembly Instructions




Figure 11

Use screws (K) to connect brackets (L) to left frame (3) and right frame (4) as shown.

Tighten screws (K) with Phillips screwdriver.

Drill 1/4 inch pilot holes in near proximity of brackets (L) attached to the left frame (3) and right frame (4), then, tap the plastic anchor (N) into the wall.

Use screws (M) to connect brackets (L) to plastic anchors (N) on wall.

Tighten screws (M) with Phillips screwdriver.

Move this item closed to the fastened wall brackets (L) and tie in both brackets (L) with plastic straps (O) as shown in diagram.

Now you can enjoy your new fireplace.

Parts Replacement Form

Name _____

Address _____

City/State/Zip Code _____

Phone Number _____

Please indicate where you purchased this item: Store/Website/Catalog

Please indicate color/size/style number:

Style No	Parts Letter	Parts Description	Quantity Needed
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____

Please examine this product carefully upon immediate receipt. Any request for missing parts or damage replacement must be received within 90 days of your receipt of the product. Replacement, if available, will be honored within this time frame. Parts will not be available for items arriving fully assembled. We do not recommend modifying product(s) and we are not responsible for any damages due to product modification(s). If damages or missing parts are not reported within 90 days of your receipt, we are under no obligation to provide parts or replacement merchandise.

Please contact Southern Enterprises at 800-633-5096 or in Dallas 972-869-0111/ 9am – 4pm Mon-Fri Central time if you have product issues or email us at service@seidal.com. Please ask for customer service representative for issues involving damages or replacement parts. Please ask for technical assistance representative for any issues with product and assembly/construction.

Please contact the retailer that you purchased from for returns.



Southern
ENTERPRISES

Customer Service 1-800-633-5096
service@seidal.com
Southern Enterprises, Inc.
600 Freeport Parkway, Suite 200
Coppell, Texas 75019