


Installation

⚠ DANGER: Before installation, turn off the main power at the circuit breaker.


⚠ WARNING: Installation must be performed by a qualified licensed electrician.

TOOLS REQUIRED FOR INSTALLATION AND ASSEMBLY (not included):




1 Removing the existing fixture

- A. Remove the existing fixture.




2 Install Fixture Mounting Screws

- A. Install fixture mounting screws (A)




3 Connecting the wires

- Connect the white supply wire to the white fixture wire.
- Connect the black supply wire to the black fixture wire.
- Connect the ground supply wire to the ground fixture wire.
- Use wire nuts to secure all connections.



4 Installing the ceiling fixture

- Install the fixture base onto fixture screws and secure by turning clockwise into slots.
- Tighten fixture housing screws. Do not over tighten.
- Install the Lens inside the fixture and turn clockwise. Hand tighten only. Do not over tighten.



LIMITED WARRANTY

The manufacturer warrants this product to be free of defects in materials and workmanship for a period of 3 years from date of purchase. This warranty applies only to the original purchaser. If this product is found to be defective, the manufacturer's only obligation and your exclusive remedy, is the repair or replacement of the product at the manufacturer's discretion, provided that the product has not been damaged through misuse, abuse, accident, modifications, alterations, neglect or mishandling. This warranty shall not apply to any product that is found to have been improperly installed, set-up, or used in any way not in accordance with the instructions supplied with the product. This warranty shall not apply to the finish on any portion of the product, such as surface and/or weathering, as this is considered normal wear and tear. The manufacturer specifically disclaims any liability and shall not be liable for any consequential or incidental loss or damage, including but not limited to any labor/expense costs involved in the replacement or repair of said product.