



nest[®]

Welcome Guide

Explore Nest

Press the ring for the menu, then rotate to select.



If you have heating and cooling, easily switch between them manually or automatically.

Schedule

See the schedule Nest has learned from your temperature adjustments. If it's not right, change it.

Energy

See how much energy you've used in the last 10 days and why.

Settings

Choose options like thermostat lock and fan control.

Away

Set it to Away when you leave to save energy while you're gone.

Meet the Nest Learning Thermostat



Display

Turns blue when cooling and orange when heating.

Status

Nest shows you Time-to-Temperature and if it's heating, cooling or using Airwave.

Current temperature

Shows the temperature in your home.

Target temperature

Shows the temperature you want to reach.

Nest Leaf

Appears when you're saving energy.


Sensor Window

Contains temperature, humidity, light and activity sensors.

Away from home


Connect Nest to Wi-Fi, then sign up for a Nest Account at nest.com/account

With the Nest app, you can adjust the temperature, change your schedule, see Energy History and control multiple thermostats.



We take your privacy seriously.
Find out more at nest.com/privacy
Visit nest.com for more info about
Nest's facts and figures.

Your life with Nest



Install & setup

Read our installation guide and watch videos at nest.com/support

Day 1

Remote control

Connect the Nest Thermostat to Wi-Fi, sign up for a Nest Account on nest.com, and download the Nest app for your smartphone or tablet.



Auto-Schedule

Nest will remember the temperatures you like and build a schedule. Teach it well by turning it down when you go to bed or leave the house.

System Match

It adapts to your system, whether you have forced air, heat pump or radiant.

Find even more detailed Energy History on the Nest app.

Day 7

Check your schedule


You can edit your schedule on the thermostat as well as the Nest app.

Changing the temperature just one degree can lower your energy use up to 5%.



Nest Leaf

The Leaf appears when you choose a temperature that saves energy.





Energy History

See when you used heating and cooling and how your temperature changes, the weather or Auto-Away affected your energy use.



Auto-Away

The Nest Thermostat automatically turns itself to an energy-saving temperature when you're away.

Save the most with Auto-Away by setting your Away "heat to" temp below 65° and your Away "cool to" temp above 80°.

Day 30

Energy Report

Your monthly Energy Report is packed with energy info and tips to help you save.

Going on vacation?
Start saving money
the minute you walk
out the door by turning
on Away manually.

Seasons change

When you switch from heat to cool or vice versa, the Nest Thermostat will learn a new schedule.

Day 90



Airwave

Lower your AC bill.
Airwave cuts AC
runtime automatically
when home humidity
isn't too high, ensuring
you stay cool.



Heat • Cool

If you need to switch
between heating and
cooling often, choose
Heat • Cool to make the
change automatically.