

Wi-Fi Function User Manual



This description is applied to Air Conditioners with Wi-Fi function. Please read the manual carefully before using the product and keep it for future reference.

Operation Steps	Operation Items	New Account	Re-install APP (registered before)
Step 1	Download and Install APP	YES	YES
Step 2	Activate APP	YES	YES
Step 3	Registration Account	YES	NO
Step 4	Login	YES	YES
Step 5	Add Device to control	YES	Registered Device will remain.

Operation guideline. Please take below simple guideline instruction as reference.

Note: If you registered the account and added device before, when you re-install the APP again and login, the added device will remain .

FCC Caution (FCC ID: 2AJCLTWAC-TYWFS)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

The distance between user and device should be no less than 20cm.

CONTENTS

1
2
3
4
6
8
10
28
30

Wi-Fi Module specification and basic information

1. Minimum specifications on a Smart phone:


Android 5.0 version or higher IOS 9.0 version or higher

2. Basic parameters for Wi-Fi module

Parameters	Details
Network frequency	2.400 - 2.500GHz
Standards of WLAN	IEEE 802.11 b/g/n(channels 1-14)
Protocol stack support	IPv4/IPv6/TCP/UDP/HTTPS/TLS/MulticastDNS
Security support	WEP/WPA/WPA2/AES128
Network type support	STA/AP/STA+AP

3. Wi-Fi module location and appearance in indoor unit

Open the front panel, the Wi-Fi module is nearby the electric box cover or on the panel.



Download and Install the App





SmartLife-SmartHome

For Android smart phone

Method1: Please scanthe QR code with a browser scanner, download and install the APP. Method2: Open the Google "Play Store" on your smart phone and search "SmartLife-SmartHome", ownload and install the APP.



For IOS smartphone

Method1: Please scanthe QR code and follow the tips toget into "AppStore", download and install the APP.

Method2: Open the Apple "AppStore" on your smartphone and search "SmartLife-SmartHome", download and install the APP.





Please enable the permissions of Storage/Location/Camera for this APP when installing. Otherwise it will have some problems when operating.

Activate APP


The first time the app is used, it will need activating.

1. Launch the APP "SmartLife-SmartHome" on your smart phone.



SmartLife-SmartHome

 Method1:Tap button "Scan" and scan the right Activate QR code Method2: Tap "or Enter Activation Code" in bottom of the screen, then enter the activate code and tap "CONFIRM".




Activate QR code and activation code



Note: Without the QR code or activation code, you can't active the APP and using it, please keep them safe.

Registration

- 1. If you don't have any account please tap button "Register".
- 2.Read the Privacy Policy and tap "Agree".



- 3. Tap">" and choose the country.
- 4.Enter your e-mail address.

←


Resister

Obtain verification code

I Agree User agreement and Privacy Policy

5. Tap the button "Obtain verification code".

Х





Search the country or slide the screen up/down to find and choose the Country.

Registration

6.Enter the verification code you received from e-mail.


7.Set the Password with 6-20 characters including characters and numbers. 8.Tap "Done".





Login

- 1. Tap "Log in with existing account".
- 2.Enter your registered account and password.
- 3. Tap "Log in" button.




Login

The first time the APP is used, Create family is needed:

4. Tap "Create family".

- 5.Create a name.
- 6.Set the location.
- 7. Choose default rooms or add new rooms.
- 8.Tap "Done" and "Completed".



Note: The app can open the map on your phone and you can set the location where you are.

choose the recommended room or make a new room, then tap Done.




Login

Forgot the password

If you forgot the password or you want to reset the password, operate as below:

1. Tap "Forgot password".


- 2.Enter your account(e-mail address) and tap button "Obtain verification code".
- 3.Enter the verification code received by your e-mail.
- 4.Set the new password and tap button "Done".




Add device

There are 2 modes CF(Quick connection) and AP(Access Point) for adding device.

- 1.Power on the indoor unit, no need to launch the air conditioner.
- 2.Click "+" in the upper right corner of the "Home" screen
 - or tap "Add device" on the room which has no device.
- 3. Tap the "Split Air conditioner" logo.
- 4.Input the password of the Wi-Fi which the same as your smart phone connected, then tap "Next".
- 5.Follow the comments on the next screen to reset the Wi-Fi module then check "Confirm the device is reset" and tap"Next".
- 6.You can see the percent rate of connecting process, at the same time PP", "SA", "AP" shining in turn on the indoor display.
 - "PP" means "Searching the router"
 - "SA" means "connected to the router"
 - "AP" means "connected to the server"







Add device


There are 2 methods to add the device. 2-AP mode

1.Power on the indoor unit, no need to launch the air conditioner.

- 2.Click "+" in the upper right corner of the "Home" screen
 - or tap "Add device" on the room which has no device.
- 3. Tap the "Split Air Conditioner" logo.
- 4.Input the password of the Wi-Fi which the same as your smart phone connected, then tap "Next".
- 5.Tap ⇒ in the upper right corner and choose "AP Mode" then follow the comments on the screen to reset the Wi-Fi module then check "Confirm the device is reset" and tap"Next".
- 6.Read the instruction carefully and tap "Connect now".
- 7.In the network setting screen, select "SmartLife-****", and tap" ← ".
- 8.You can see the percent rate of connecting process, at the same time "PP", "SA", "AP" shining in turn on the indoor display.
 - "PP" means "Searching the router"
 - "SA" means "connected to the router"
 - "AP" means "connected to the server"







The device control screen will pop up automatically after adding the device.


The device control screen will pop up manually by tapping the device name on the home screen.



Note:

There are two different control forms base on different software or Wi-Fi module firmware. Please read the manual carefully base on the real control interface.






Control form2



Control form1



The main control interface


Control form1-Mode setting

- 1. Tap Mode to pop up the Mode screen.
- 2.Select one of the mode Feel/Cool/Heat/Dry/Fan.
- 3. Tap anywhere around the setting temperature to cancel the Mode setting.



Control form1-Select fan speed

- 1. Tap Fan to pop up the Fan screen.
- 2.Select one of the fan speed High/med/Low/Auto.
- 3. Tap anywhere around the setting temperature to cancel the selection.



Control form1-Function setting

1. Tap Function to pop up the Function screen.

2.Select one of the functions Sleep/Turbo/ECO.


3.Select UP-DOWN/LEFT-RIGHT for auto swing with direction of UP-DOWN/LEFT-RIGHT.


4. Tap anywhere around the setting temperature to cancel the Function setting.



Control form1-Timer adding

Tap Timer to pop up the Add Timer screen.
 Tap Add Timer.






Control form1-Timer adding

3.Select the time, select the repeat days and Timer on/off.

4.Select the Mode/Fan speed/Function and select the setting temperature for Timer on. 5.Tap Save to add the timer.



Control form1-Timer Management


1. Tap the bar of timer to edit the Timer like the Timer adding process.

2.Click the switch to enable or disable the Timer.

3.Holdind the bar of Timer about 3seconds and pop up the Remove Timer screen, tap CONFIRM and remove the Timer.

< Add Timer	
Timer accuracy is -/+ 30 seconds	
12:20 Once Timer:Off	Remove Timer
12:20 Mon, Tue, Wed, Thurs	
Timer: On 16 [°] C Cool Turbo UP-DOWN	
Add timer	

Control form2



The main control interface

Control form2-Mode setting

- 1. Tap the Mode button.
- 2. There are 5 modes on the Mode screen, tap one button to set the Air conditioner working mode.
- 3. Tap the X button to back the main control screen.
- 4. The mode and background will change on the screen.





Note: please read the details of each mode in the user manual to control more comfortable.

Control form2-Fan speed selection

- 1. Tap the Fan speed button.
- 2. Choose your desired fan speed and tap it.
- 3. Tap the X button to back the main control screen.
- 4. The selected fan speed indicator will appear on the screen.






Mode	Fan Speed		
Cool	All speeds		
Fan	All speeds		
Dry			
Heat	All speeds		
Auto	All speeds		

Note:

Fan Speed can't be adjusted on Dry mode .

Note: Fan Speed screen mayappear slightly different , depending on the air conditionermodel. Example as below:





Control form2-Air Flow control

- 1. Tap the Precision Air Flow button or Swing Flow button.
- 2. Choose your desired air flow and tap it.
- 3. Tap the X button to back to the main control screen.
- 4. The selected air flow indicator will appear on the screen.


Note: For some models without auto Left-Right wind, If you active it, you will hear a beep, but no any actions.








Note: The Main controlscreen and Air Flowscreen may appear slightly different , depending on the airconditioner model. Example as below:



Control form2-ECO function

- 1.For Eco function, just tap the button to activate the function, the button will be lighting and the indicator will appear on the screen.
- 2. Tap again to disable the function.
- 3. Temperature controlled for some air conditioner model: In Cooling mode, the new setting temperature will \ge 78 °F. In heating mode, the new setting temperature will \le 77 °F.



Mode	ECO enabled
Cool	Yes
Fan	
Dry	
Heat	Yes
Auto	

ECO is disabled on Fan/ Dry/Auto mode .

Note: The Main controlscreen and ECO control method may appear slightly different, depending on the airconditioner model. Example as below:



Note:


ECO is disabled on Turbo/Sleep mode too for some air conditioner model.

Control form2-Sleep function

1. Tap the Sleep button.

- 2. Choose your desired sleep mode and tap it.
- 3. Tap the X button to back to the main control screen.
- 4. The selected sleep mode indicator will appear on the screen.





Mode	Sleep enabled
Cool	Yes
Fan	
Dry	
Heat	Yes
Auto	

Sleep is disabled on Fan/ Dry/Auto mode .

Note:

The Main controlscreen may appear slightly different ,dependingon the air conditioner model. Example as below:





Note:

Sleep is disabled on Turbo/Sleep mode too for some air conditioner model..

Control form2-Timer(on) setting


1. Tap the Timer button.


2.Tap + in the upper right corner of the Timer main screen.

3. Choose the Time/Repeat/Switch OFF then tap Save.

4. The timer (off) will appear on the Timer main screen.







Control form2-Timer(off) setting


1. Tap the Timer button.

- 2.Tap + in the upper right corner of the Timer main screen.
- 3.Set the Time/Repeat Date/Switch(ON)/Temperature/Mode/
- Fan speed/Air Flow as your desired and then tap Save.
- 4. The timer will appear on the Timer main screen.





┉



desired as mentioned on the previous chapter and tapConfirm the setting.

Tap repeat> then tap your desired

Control form2-Timer management

1. Change the Timer setting:

Tap anywhere of the timer list bar except the switch bar to get into the Timer setting screen, change the setting and then tap save.


2. Enable or Disable the Timer:

Tap the left of the switch to disable the Timer. Tap the right of the switch to enable the Timer.

3.Delete the Timer:

Slide the list bar of the Timer from right to left until Delete button appear, then tap delete.








Control form2-More functions


1. Tap the More button to operate additional functions if it appears on the screen.



It activate the antibacterial ioniser function. This function only for models with the ioniser generator.

Tap the "GEN Mode" button, if it is available on the screen.
 In this Mode, you can choose one of the three levels of current.
 The air conditioner will maintain proper current to save energy.

GEN Mode►



Control form2-More functions

7. Tap the "Electricity Monitoring" button if it is available on the screen. In this function, you can monitor the air conditioner electricity consumption.



You cantap this button to pop up the calenderthen select the date.

mì 8. Tap the button, if it is available on the screen. Self-Cleaning

Check the details of the Self-Cleaning function on User Manual.

9. Tap the "8°C Heat" button , if it is available on the screen. This function help keep the room temperature over 8° C. Check the details of the 8° Heat function on User Manual.



vou

10.Tap the "Reservation" button, if it is available on the screen.

Reservation

You can set the time, repeat day, temperature, mode, fan speed, air flow as you desired and then tap Save to activate the function.


The air conditioner will automatically reach your settings at the appointment time.

< Re	eservation	< Reservation
14 15 16 17	17 18 : 19 20	16:19:00 ON,Cool,Mid,Up-Down Swing 25
18	20	After the reservation is set up, the air condit will automatically reach your set requiremen appointment time.
Repeat setting	Monday>	
Temperature	25℃>	
Mode	Cool>	
Fan Speed	Mid>	-

Control form2-More functions

11. Tap the "Self-diagnosis" button, if it is available on the screen.

The air conditioner will automatically diagnosis itself and indicate the Error code and the problem instructions if possible.



12. Tap the "

" button if it is available on the screen.

This function allow the air conditioner to turn on/off the display automatically according to the light intensity.

13. Tap the " Soft Wind


Photosensitive

" button if it is available on the screen.

In this function, the air conditioner will blow soft airflow through the micro holes on the deflector.

Device details and management

Tap \swarrow on control form1 or tap ... on control form2, get into the device details screen. Here you can get some useful information and sharing the device to other accounts. Check the following pictures and instructions carefully.



Control form1

Control form2



	Oetails of device	
	Information	
Tap to change the device location to another room	Device Location Dining Ro	
	Check Device Network Check	Now >
	Supported Third-part Control	
	amazon alexa Google Assistant	-
	Others	
	Device Sharing	>-
	Device Info	> -
Feed back the problems or some —	Feedback	>
suggestions to the APP administrator.	Check for Firmware Update	> .
	Remove Device	

Device details and management


How to share the devices to other accounts?

- 1. Tap "Device Sharing" and pop up Device Sharing screen.
- 2. Tap "Add Sharing".
- 3. Select the region and enter the account which you want to sharing.
- 4. Tap "Completed", the account will appear on your sharing list.
- 5. The received sharing members should hold pressing the home screen and slide down to refresh the device list, the device will appear on the device list.

< Details of device	< Details of	f device	← Ad	d Sharing Completed
Information	It is recommended to set perm member to control the device F			0
Modify Device Name*** >Device LocationDining Room >Check Device NetworkCheck Now >		anny secongs	Region	China +86 >
Supported Third-part Control			Account number	****
amszon alexa Google Assistant				
Others				
Device Sharing > Create Group > Device Info > Feedback > Check for Firmware Update >				
Remove Device	Adding sha	ring S		
Details of device It is recommended to set permanent resident as family member to control the device Family Settings Sharing List Data Name1	Hold the bar about 3s then you can delete the sharing account.	- Set you informa	Noom Master Bedroom	Hold on and slide down to refresh the device list
Adding sharing		Home) Me	

Account management


Account Profile setting




Home(Family) management

1. Tap the name of home at the left upper corner of the Home Screen and select the Home Management. Or tap Me and tap Home Management.

2. Tap one of the families in the family list and get into Family Settings screen.



3.Set the family as the following indicators.



Notice

- 1. For technical update, there is maybe deviation of the actual items from what is on the manual. We express our apologies. Please refer to your actual product and APP.
- 2. Smart air conditioner APP can be altered without notice for quality improvement and also be deleted depending on the circumstances of manufacturing firms .
- 3. In case Wi-Fi signal strength is weakened, smart App may be disconnected. So make sure the indoor unit near to wireless router.
- 4. DHCP server function should be activated for wireless router.
- 5. The internet connection may fail because of a firewall problem. In this case, contact your internet service provider.
- 6. For smart phone system security and network setting, make sure Smart air conditioner APP is trusted.

Trou	ble Sh	ooting
II C G		

Description	Analysis of cause
Air conditioner can't be configured successfully	 Check the mobile connected WLAN router SSID and password is correct; Check whether there are additional settings of WLAN router as shown below. Firewall by router itself or by PC MAC address filtering Hidden SSID Hidden SSID HOHCP server Reboot WLAN router, mobile device and air conditioner (WLAN module) and connect air conditioner by CF mode again. Before rebooting, check nobody has already connected to same air conditioner.
Mobile can't control air conditioner	 When air conditioner (WLAN module) is rebooted and app displays Device remove, ignoring this confirmation will lead to mobile device losing control permission of the air conditioner. You will need to connect the air conditioner by CF mode again. In case of power failure, mobile device will lose control permission of air conditioner for 3 minutes after power failure. (Notification will now show up on the mobile device.) If you cannot control the app (air conditioner) even after power restored, you will need to connect the air conditioner by CF mode again.
Mobile can't find air conditioner	 App display Air conditioner Device offline. Please check the following conditions. The air conditioner has been reconfigured. Air conditioner out of power. Router out of power. Air conditioner can't connect to router. Air conditioner can't connect to network through the router. Mobile device can't connect to network. After adding the device, it disappears in device list . Hold and slide down to refresh the device list. If it has no change, shut down the app and start again.

TROUBLESHOOTING & WARRANTY

BEFORE YOU CALL FOR SERVICE

IF THE AIR CONDITIONER FAILS TO OPERATE:

- A) Check to make sure that the air conditioner is plugged in securely, if it is not, remove the plug from the outlet, wait 10 seconds and plug it in again securely.
- B) Check for a blown circuit fuse or a tripped main circuit breaker. If these seem to be operating properly, test the outlet with another appliance.

C) Check if electricity to the main power switch of the unit appears to be working.

D) Make suere that both units are in the upright position.

IF NONE OF THE ABOVE SOLVES THE PROBLEM, CONTACT A QUALIFIED TECHNICIAN.



WARNING: DO NOT TRY TO ADJUST OR REPAIR THE AIR CONDITIONER YOURSELF.

CUSTOMER SERVICE

IMPORTANT

If you have a problem with this product, please contact the below

DATED PROOF OF PURCHASE, MODEL # AND SERIAL # REQUIRED FOR WARRANTY SERVICE

Customer & Technical Support Information (Please contact us BEFORE returning product)

Website: www.auxusa.com Contact Phone # : 1-909-979-9892(Mon-Fri, 9am-5pm/PST) Email: support@auxusa.com