

3 in 1 SOLAR BALL LIGHT

ITEM #0128058

MODEL #SPFL-1M

READ ALL INSTRUCTIONS COMPLETELY BEFORE USE. SAVE INSTRUCTIONS FOR FUTURE USE.

PARTS

A - Ball (Light)

B - Base

C - Stake

D - Anchor point

(Refer to Fig. 1)




Fig. 1

WAYS TO USE

1. Ball (light) may be placed on a table or any flat surface by using the black base provided. The anchor point may be used to keep light fixed in the base.

2. Ball (light) may be placed in the dirt, grass or any other soft surface by using the stake provided.

3. Ball (light) may be placed directly in a pond or pool. The anchor point may be used, along with a string, to keep ball (light) from moving too far in the water.

(Refer to Fig. 2 for "Ways to Use")




Fig. 2

The ON/OFF switch, located on the bottom of the ball, has 2 settings--one for ON and one for OFF. **The ON/OFF switch will be pre-set in the OFF position when ball (light) is brand new.**

(Fig. 3)

IMPORTANT: Batteries in the solar ball light will need to charge for 24 hours when using for the first time. Place solar ball light in an area that will allow it to receive FULL SUN in order for rechargeable batteries to reach maximum charge.

***PLEASE NOTE: The ON/OFF switch must be in the OFF position for the batteries to charge the first time.**




Fig. 3

BATTERY REPLACEMENT

1. Remove the waterproof seal by turning it *counterclockwise*.
2. Lift battery cover.
3. Remove old batteries. (Refer to "Battery Disposal" below for proper disposal.)
4. Install 2 new AAA rechargeable batteries only. [NOTE: Replace both batteries at the same time; do **not** mix old and new batteries.]
5. Align blue button in battery compartment with ON/OFF label on battery cover and replace battery cover.
6. Replace waterproof seal and tighten securely by turning *clockwise*. Do NOT overtighten waterproof seal as it may crack or break.

(Refer to Fig. 4 for "Battery Replacement")

⚠ WARNING

This light has passed the waterproof test prior to shipment. Therefore, do NOT open any compartment except for the battery compartment. To avoid leakage and damage to the light, it is extremely important to make sure to replace the battery cover correctly and to tighten the waterproof seal securely when replacing batteries.

BATTERY DISPOSAL

Please help to preserve the environment by disposing of batteries in accordance with local, state and federal regulations.



WARNING: Batteries must **NOT** be disposed of in the regular trash nor thrown into a fire as batteries may leak or explode. Contact the **Rechargeable Battery Recycle Center (RBRC)** at 1-800-822-8837 or go to **Earth911.com** for information on where to recycle the battery.

WARRANTY*

Litex Industries warrants this product* against defects in materials and workmanship for one (1) year from the date of purchase. If within this period the product is found to be defective, take a copy of the bill of sale as a proof of purchase and the product in its original carton to the place of purchase. Litex Industries will, at its option, repair, replace or refund the purchase price to the consumer. All costs of installation and removal of the product is the responsibility of the consumer. This warranty does not cover products becoming defective due to acts of God, misuse, accidental damage or improper handling and/or installation and specifically excludes liability for direct, incidental or consequential damages. As some states do not allow exclusions of limitations on an implied warranty, the above exclusion and limitation may not apply. This warranty gives you specific rights and you may also have other rights which may vary from state to state.

*Stake, Anchor Point and Base are excluded from warranty.

CUSTOMER SERVICE

1-800-527-1292, M - F, 8:30AM-5:00PM, CST




Fig. 4