

ITEM #0093089 MODEL #C-J-109D Français p. 07 Español p. 13

REPLACEMENT CANOPY

Purchase Date _____

1

Lowes.com/gardentreasures

garden treasu treasures

garden

garden treasures

garden treasures.

> garden treasures.

Printed in China

g garden

Garden Treasures® is a registered trademark of LF, LLC. All rights reserved.

Lowes.com/gardentreasures

Lowes.com/gardentreasures

Lowes.com/gardentreasures

Lowes.com/gardentreasures

3

4

5

6

Lowes.com/gardentreasures

Questions, problems, missing parts? Before returning to your retailer, call our customer service department at 1-800-643-0067, 8 a.m. - 8 p.m., EST, Monday - Friday.

DESCRIPTION

Wind Vent Canopy

SAFETY INFORMATION

· Item is heavy. Handle with care. Need four adults for safe assembly.

Estimated Assembly Time: 1 hour

ASSEMBLY INSTRUCTIONS

To remove original canopy:

canopy (B).

• The gazebo is not intended to be a permanent structure.

This canopy is intended to be attached to Item #0092839.

Remove the original top insect net (C). Open the hook-and-loop fasteners in the top crossbar

and valance corners of original large

2. Take out four large canopy frames from four pockets of original large canopy (B). Remove 4 long bolts, 8 metal washers and 4 large nuts.

3. Place the whole canopy frame on the ground. Take out four wind vent canopy bars from four pockets of original wind vent canopy (A) and remove original wind vent canopy (A).

ASSEMBLY INSTRUCTIONS

Phillips screwdriver.

To attach new canopy:

canopy bar down.

ASSEMBLY INSTRUCTIONS

8. Insert a short bolt through a "U" bracket,

completely using Phillips screwdriver.

9. Place the new wind vent canopy (A) over the

pockets of the new wind vent canopy (A).

10. Place the fully assembled canopy on top of

hole. Tighten all bolts completely.

ASSEMBLY INSTRUCTIONS

CARE AND MAINTENANCE

ONE-YEAR LIMITED WARRANTY

for personal, residential purposes.

natural causes are not covered.

11. Pull down and level the valances of new large

canopy (B). Insert large canopy frame into the corner pockets of the new large canopy (B). (Note: It can be a little difficult to complete this step. This is normal.) Fasten all hook-and-loop fasteners on the new large canopy (B). Attach the new top insect net (C) to the new large

canopy (B). Note: Make sure the hook-and-loop connectors are wrapped around the crossbar.

Wash with mild soap. Rinse with water and let air dry.

assembled panel posts. Align the holes, insert a long bolt through a metal washer, an "L" bracket, a large canopy bar, another metal washer and secure with a large nut for each

10

5

This warranty is extended to the original purchaser and applies to defects in materials and

Replacement canopies may be available for purchase on Lowes.com if out of warranty.

The manufacturer, at its option, will repair or replace the defective parts.

you may also have other rights which vary from state to state.

Exclusions: Items used for commercial, contract or other non-residential purposes; display models; items purchased "as is;" or items damaged due to acts of nature, vandalism, misuse or improper assembly are not covered. Discoloration or fading of the finish or fabrics as a result of exposure to the elements, chemicals or spills is not covered. Tabletop breakage, corrosion or rusting of hardware and damage to frames or welds caused by improper assembly, misuse or

workmanship of your patio furniture provided your furniture is maintained with care and used only

If within the stated warranty period a product is found to be defective in material or workmanship, the purchaser must contact the manufacturer's customer service department at 1-800-643-0067.

Warranty is to the original purchaser and is non-transferable. Any replacement of warranted items will be in the original style and color or a similar style and color if the original is unavailable or has been discontinued. As some states do not allow exclusions or limitations on an implied warranty, the above exclusions and limitations may not apply. This warranty gives you specific rights, and

6

7

9

10

11

12

11

wind vent canopy bar, slipping bars into corner

through the wind vent canopy bar and secure with a small nut for each hole. Tighten all bolts

4. Remove 4 short bolts and 4 small nuts using

5. Adjust the wind vent bar position as shown.

6. Adjust the wind vent bar position as shown.

7. Place the new large canopy (B) on the large canopy frame, and then let the wind vent

Remove the original large canopy (B).

Large Canopy

Top Insect Net

QUANTITY

1

1

1

Please read and understand this entire manual before attempting to assemble or install

• Assemble the item on a soft, non-abrasive surface such as grass to avoid damage.

• Take the gazebo down during high winds or inclement weather or it may be damaged.

any foreign substance to the canopy fabric may render the flame-resistant properties

Before beginning assembly of product, make sure all parts are present. Compare parts with

Helpful Tools (not included): Phillips screwdriver, Allen wrench and open hex wrench.

package contents list. If any part is missing or damaged, do not attempt to assemble the product.

2

• KEEP ALL FLAME AND HEAT SOURCES AWAY FROM CANOPY FABRIC. This canopy is made with flame-resistant fabric, which meets CPAI-84 specifications. It is not fireproof. The canopy fabric will burn if left in continuous contact with any flame source. The application of

PART

Α

В

С

the product.

WARNING

ineffective.

PREPARATION

ATTACH YOUR RECEIPT HERE Serial Number ___ XXXXXX PACKAGE CONTENTS