



HAYDEN ISLAND DINING TABLE

> MODEL #SS-359-8T Français p. 06 Español p. 11



ATTACH YOUR RECEIPT HERE
Serial Number ______ Purchase Date ______

Questions, problems, missing parts? Before returning to your retailer, call our customer service department at 1-800-643-0067, 8 a.m. - 8 p.m., EST, Monday - Friday.
XXXXXX
Lowes.com/gardentreasures
1 **BACKACE CONTENTS**



Please read and understand this entire manual before attempting to assemble or install the product.

spare

2

(not to scale)

garden treasures

Q

Lowes.com/gardentreasures

(not to scale)

spare

Assemble the table on a soft, non-abrasive surface, such as carpeting, to avoid damage.
Item is heavy. Handle with care.
Two adults may be needed to assemble.

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 1 hour

Tools Required for Assembly (included): Allen wrench Helpful Tools (not included): Phillips screwdriver


ASSEMBLY INSTRUCTIONS

Remove 12 bolts (AA) and 12 metal washers that are attached to the legs (C).

 Place the table top (A) upside down on a non-abrasive work surface and insert six legs (C) into the plastic receivers on the table top (A), working the legs in until the holes in the legs (C) line up with the holes in the receivers of the table top (A).



Lowes.com/gardentreasures



CARE AND MAINTENANCE

Wash with mild soap. Rinse with water and let air dry.

ONE-YEAR LIMITED WARRANTY

This warranty is extended to the original purchaser and applies to defects in materials and workmanship of your patio furniture provided your furniture is maintained with care and used only for personal, residential purposes.

Frames are warranted to be free from defects in material or workmanship for a period of one (1) year.

Exclusions: Items used for commercial, contract or other non-residential purposes; display models; items purchased "as is;" or items damaged due to acts of nature, vandalism, misuse or improper assembly are not covered. Discoloration or fading of the finish or fabrics as a result of exposure to the elements, chemicals or spills is not covered. Tabletop breakage, corrosion or rusting of hardware and damages to frames or welds caused by improper assembly, misuse or natural causes are not covered.

If within the stated warranty period a product is found to be defective in material or workmanship, the purchaser must contact the manufacturer's customer service department at 1-800-643-0067. The manufacturer, at its option, will repair or replace the defective parts.

Warranty is to the original purchaser and is non-transferable. Any replacement of warranted items will be in the original style and color or a similar style and color if the original is unavailable or has been discontinued. As some states do not allow exclusions or limitations on an implied warranty, the above exclusions and limitations may not apply. This warranty gives you specific rights, and you may also have other rights which vary from state to state.

5

Printed in China Garden Treasures[®] is a registered trademark of LF, LLC. All rights reserved.

Lowes.com/gardentreasures

garden treasures