


Measuring Guide


Two-Piece Wicker Chair Cushion



1 Seat Width


- Measure the width from side to side, across the front of the seating area, between the arms of the chair.

If your chair doesn't have arms, measure the widest part of the seat, from edge to edge.




2 Seat Depth

- Measure the depth from the front of the seating area to the back, or where the back and seat meet.
- Add one inch to your measurement to ensure proper cushion fit and maximum comfort.



3 Back Height

- Measure the height from the top of the chair back down to the back of the seat, or where the back and seat meet.
- Subtract the thickness of your seat cushion from the total height of the chair back.



4 Back Width

- Measure the width of the seat back, from one side to the other.