



6 Place Setting Countertop Dishwasher

PRODUCT MODEL NUMBERS

HDC2406TW

DISHWASHER INSTALLATION

Determine the best location for your new Countertop Dishwasher. It must be close to a 120 Volt (15 Amp) outlet and a sink with a water supply and drain. The minimum height clearance required to install your dishwasher on a countertop surface with overhead cupboards/ Kitchen cabinets is 17.8" (45cm). This Space Saving Countertop Dishwasher is 17.2" in height.

- It is suggested that you place the dishwasher right next to the sink.
- Make sure there is an electrical power supply within easy reach of the machine. The power cord is 6 foot long.
- The dishwasher must be installed on a solid, level surface.
- To level the dishwasher, adjust the four legs under the dishwasher.

ELECTRICAL CONNECTIONS

Important-for personal safety, this appliance must be properly grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current. This appliance is equipped with a cord having a grounding wire with a grounding plug. The plug must be plugged into an outlet that is properly installed and grounded. Consult a qualified electrician or service center if the grounding instructions are not completely understood. If doubt exists as to whether the appliance is properly grounded, have a qualified electrician check the circuit to make sure the outlet is properly grounded.

Do not, under any circumstances, cut or remove the third (ground) prong from the power cord.

USE OF EXTENSION CORDS

Avoid the use of an extension cords due to potential safety hazards under certain conditions.

OVERALL DIMENSIONS

Model Size	Cabinet Dimensions		
	A-Height	B-Width	C-Depth
6 Place Setting	17.2"	21.7"	21.7"

