


Bosch Product Dimensions

Bosch Dishwashers

Models: All SHX Models



in inches

SHX -24" TallTub Dishwashers	
Width	24" to 24 ¼" (23 5/8" with décor strips removed)
Height	34" to 35" (36" with Custom Toe-Kick *Always use included metal toe-kick behind custom toe-kick)
Depth	24"
Upper Clearance	Leave 1/8" to 1/4" of space between the countertop and the dishwasher
***SHX models do not accept custom panels.	

