

Installation

Check your mower for sharp corners or edges that could stress your cover as you pull it on.

Look for a white tag sewn in the bottom hem that says "front". Slip your cover over the top of your mower with the white tag at the front, then pull the cover down on all four corners.

Cleaning and Care

Clean your cover with a soft brush and luke-warm water or machine wash in COLD water. DO NOT USE SOAP as it may remove the protective coatings added by the factory. Dry on air or delicate.

Storage

A handy integrated storage bag is sewn into your cover. Just stuff your cover into it. To avoid mildew be sure your cover is completely dry before you store it in the storage bag for a long period.

Two Year Warranty

This cover is factory warranted for workmanship and materials for two years after purchase. This warranty assumes normal use and conditions. Use while trailering your mower will invalidate the warranty.