Solar Light

Questions or problems?
Before returning to your retailer, call our customer service at 1-800-887-6326.
Monday – Friday 9:00 a.m. – 5:00 p.m. CST

PACKAGE CONTENTS

Includes (1) AAA 300 mAh(1.2V) Ni-MH rechargeable battery.


LED The lifetime for LEDs is estimated to be 100,000 hours. It should never need to be replaced.

Includes (2) dry wall screws.

Includes (2) anchors.

REF. PARTS NAME

A Top Cap
B Deck Light



⚠ Read all instructions before assembly. Failure to do so may result in faulty assembly and potential injury.

FUNCTION: The built-in solar panels convert sunlight into electricity. The rechargeable battery stores the energy and converts the power into light for use during the night. The lighting hours of the solar light depends on the geographical location, weather condition and temperature condition. Stronger or longer exposure to sunlight enables the battery to store more energy and provide longer lighting hours.

LOCATION: It is important to select an outdoor location with full, direct sunlight where the solar panel can receive at least 8 hours of sunlight each day. Shady areas will not enable batteries to be fully charged. This will reduce the lighting hours at night. It is also important to avoid placing the solar light by light sources, such as street lights or porch lights, which may cause the solar light to turn off automatically. The solar light is designated for outdoor usage and ideal for night lighting of garden, paths, etc.


CLEANING AND MAINTENANCE: Please use a damp cloth to clean the solar panel. Do not use any chemical or abrasive cleaner. It is important to ensure that no moisture enters into the solar light.


RECHARGEABLE BATTERY: This product contains (1) AAA 300 mAh(1.2V) Ni-MH rechargeable battery. When the battery expires, it must be recycled or disposed of properly. Please contact your local waste disposal authority for correct procedure. Do not put battery into fire.

ASSEMBLY AND BATTERY REPLACEMENT INSTRUCTIONS

ASSEMBLY (See Fig.1, Fig.2)

- Remove the top cap (Part A) by pulling it upward.
- Remove the insulated paper.
- Re-install the top cap (Part A) on the deck light (Part B).
- Attach the deck light (Part B) to the desired position.
- Mark the position of the two holes on the post where the anchors will be placed.
- Remove the deck light (Part B) from the post, and drill two holes on the target. hammer the anchors into the holes of the post, and then hammer the drywall screws to anchors in part way.
- Re-attach the deck light to post by inserting the dry wall screws into the two hole at the back of the deck light(Spacing is 50 mm)
- Slide the deck light (Part B) down to lock it.






OPERATIONAL INSTRUCTIONS

- After assembling, take the light to direct sunshine that allows the rechargeable battery to reach its maximum capacity. Ensure the light is in full sunlight for 8 hours. The unit will then automatically light up at dusk.

CHANGING BATTERIES (Fig.3)

- Remove the top cap (Part A).
- Remove the battery cover on the back of top cap (Part A) (Fig.3).
- Remove the old battery and replace it with an new AAA 300 mAh(1.2V) Ni-MH rechargeable battery.



TROUBLESHOOTING

If light does not work, to locate the defect, please follow these steps:

✓Check the rechargeable battery and make sure that it is in contact to the metal plate and the polarity is correct. If the battery is worn out, replace the battery with (1) AAA 300 mAh(1.2V) Ni-MH rechargeable battery.
✓ Always keep the solar light distant from other night light sources, such as exterior lights. Reposition the light to avoid close contact with other night light sources.
✓Make sure solar panel is clean and free of dirt and debris. If needed use a damp cloth to clean the solar panel. Do not use any chemical or abrasive cleaner. It is important to ensure that no moisture enters into the solar light.

ONE-YEAR LIMITED WARRANTY: If, during normal use, this PATRIOT LIGHTING® lighting fixture breaks or fails due to a defect in material workmanship within one (1) year from the date of original purchase, simply bring this lighting fixture with the original sales receipt back to your nearest MENARDS® retail store. At its discretion, PATRIOT LIGHTING® agrees to have the product or any defective part(s) repaired or replaced with the same or similar PATRIOT LIGHTING® product or part free of charge, within the stated warranty period, when returned by the original purchaser with original sales receipt. This warranty; (1) excludes expendable parts including but not limited to light bulbs and batteries; (2) does not cover damage that has resulted from abuse or misuse; and (3) does not cover any losses, labor, injuries to persons/property or costs. This warranty does give you specific legal rights and you may have other rights, which vary from state to state.

Questions or problems?
Before returning to your retailer, call our customer service at 1-800-887-6326
Monday – Friday 9:00 a.m. – 5:00 p.m. CST