



PACKAGE CONTENTS


PART	DESCRIPTION	QUANTITY		
		P300342	P300343	P300344
A	Fixture	1	1	1
B	Glass Shade	2	3	4
C	Socket Ring	2	3	4
D	Screw	2	2	2
E	Decorative strap	1	1	1



P300342




P300344



P300343

HARDWARE CONTENTS (not actual size)

AA	BB	CC	DD	EE
				
Screw (#8-32) Qty:2	Wire nut Qty:3	Round Mounting Plate Qty:1	Hex nut (#8-32) Qty:2	Cylinder nut (#8-32) Qty:2



Missing parts? Please contact Customer Service at 1-800-447-0573,
8am-8pm (Eastern), Monday - Friday, or at customerservice@progresslighting.com