




Item # 701255

CHAIR - PAIR ASSEMBLY INSTRUCTIONS




ATTACH YOUR RECEIPT HERE

Order Number _____ Purchase Date _____



Questions, problems, missing parts? Before returning to your retailer, email our customer service department directly at HELLO@LEISUREMADE.COM or call us at (888) 682-3012 8am-4pm EST, Monday-Friday.


PACKAGE CONTENTS



PART	DESCRIPTION	QTY
A	Front Chair Leg, Left	1
B	Front Chair Leg, Right	1
C	Back Chair Leg, Left	1
D	Back Chair Leg, Right	1
E	Chair Back	1
F	Chair Seat	1
G	Supporting Bar	1

HARDWARE CONTENTS

AA



M8 Bolt x 45mm
Qty: 14

BB




Washer
Qty: 14

CC



M8 x 12mm
Qty: 2

DD



Allen Key
Qty: 2

SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate or install the product.

 **CAUTION:** Assemble on a soft, non-abrasive surface.

PREPARATION


Before beginning assembly of product, make sure all parts are present. Compare parts with the package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

If you find a missing or damaged part, please look through all pieces to make sure nothing else is missing or damaged. Compile a comprehensive list and give us a call. We will send out all parts in a single shipment. Ensuring you have all missing parts identified at the time you call will ensure a faster delivery to complete your beautiful patio furniture.


Please call us directly, not your retailer. As the manufacturer we can walk you through any issues you may have. We are here to help: (888) 682-3012

ASSEMBLY CONTENTS


1. Place Chair Seat (F) on its side and attach Back Right Chair Leg (D) using bolt (AA) and washers (BB) using the allen key (DD).




2. Repeat Step 1 with the Back Left Chair Leg (C).



3. Take the assembled chair seat and attach Front Chair Leg (A) with hardware (AA) (BB) and (CC) using the allen key (DD).




4. Before attaching the other front leg, attach the Support Bar (G) into the predrilled holes. Attached it using bolt (AA) and washer (BB).




ASSEMBLY CONTENTS

5. Attach Front Leg (B) using bolt (AA) and washers (BB) using the allen key (DD) to both the Balk Leg and Support Bar.



6. Attached the Chair Back (E) using bolts (AA) and Washers (BB) on both sides.



7. Now it's time to enjoy your new furniture! If you have any issues please call (888) 682-3012 directly.

