



## Non-Automatic Submersible Utility Pump Quick Start Guide

MODEL #PPU33 ITEM #0094086

LF, LLC. All Rights Reserved. Utilitech® is a registered trademark of


This guide neither supplements nor replaces the instruction manual. Please see the instruction manual for further detailed information.





1. Attach garden hose directly to pump, OR attach the 1 1/4 in. adapter (included with pump) to pump, and then attach Hose Kit (Item #0313726) to the adapter. Slope hose away from pump to prevent backflow





•Minimum 5/8 in. diameter hose


•Maximum length 50 ft. (shorter is better)

Make sure there are no kinks in the hose

## Place pump in water.

Must be minimum of 1 in. of water for pump to work. Pump can be totally covered with water. Place upright on a flat surface


If you have any questions about this pump, please call customer service at **866-994-4148**.



## 3. Plug pump into 3-prong GFCI outlet

AWARNING: Do not let plug fall in water

NWARNING: Do not stand in water while plugged in



4. Allow pump to run; monitor its progress-Remove remaining water manually. has water that can drain back through the pump. Remove pump and hose from location, as hose still approximately 1/4 in. (DO NOT allow to run dry). UNPLUG when pump has removed water down to

Printed in China