



1. Don't power on the device before fill the water into the tank !
2. Don't keep heat the device after emptying the tank !
3. Please power off the device, wait for water turns room temperature, then you can drain off the water of the tank !

## DIGITAL ULTRASONIC CLEANER

5130

Set °C Actual °C



TEMP+



TEMP-



ON/OFF

DIGITAL PRO+

ON



TIME+

ON



TIME-



ON/OFF

Minute

Second

0400

0000

### ADMONITION!!!

The unit must be connected to ground.

Do not disassemble the unit except for the authorized serviceman.

Do not touch the socket with wet hand to reduce the risk of electrocution.

Do not use this unit when the tank is not to fill the water.

10.8"/275 mm

12.8" / 325 mm

6.9" / 175 mm