

WARNING

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug, if it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not attempt to defeat this safety feature.














CARE AND MAINTENANCE

Unplug lamps before using any cleaning solutions. Dust shades with a feather duster or with an appropriate vacuum-brush attachment. Wipe with a soft, dry cloth and clean lamp bases with the methods appropriate to the material. Avoid the use of chemicals and household cleaners as they may damage the finish.

NOTICE & IMPORTANT SAFETY INSTRUCTIONS

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * To reduce the risk of fire, electrical shock or injury to persons or property, please follow the guideline below for safe use and installation
- * The external flexible cable or cord of this luminaire cannot be replaced
- * If the cord is damaged, the luminaire shall be destroyed


Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY	PIECE	DESCRIPTION	PICTURE	QUANTITY
A/B/C	Lamp Body		1X	J	Shade		1X
D	Neck		1X	K	Bottom Ring		1X
E	Wood Tracy		1X	L	Finial		1X
F	Saddle		1X	M	Bulb		1X
G	Socket		1X	N	Wrench		1X
H	Harp		1X	O	Nut		12X
I	Top Ring		1X				



Model# FLL4119A




Product Dimensions: 22"L X 22"W X 60.25"H



PREPARATION

- * Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
- * If any part is missing or damaged, do not attempt to assemble the product.
- * Estimated Assembly Time: 6 minutes.
- * If you are having difficulty, our friendly Customer Care team is always here to help. Please email customersupport@safavieh.com

NOTE: PLEASE USE ON/OFF TYPE "A" BULB MAX 100-WATT OR LED BULB MAX 12-WATT, THERE IS LED 9-WATT BULB IN THE BOX




Step 1: Put the Lamp body (A2/B2/C2) onto the Lamp body (A1/B1/C1),Screw the nut (O) onto the lamp body with wrench(N),and tighten securely. Put the Neck (D) onto the Lamp body, Screw the nut (O) onto the Neck (D) with wrench(N),and tighten securely. Put the Wood Tracy (E) onto the Lamp body,Screw the nut (O) onto the lamp body with wrench(N), and tighten securely. Be careful not to twist the power cord and tighten securely






Step2: Insert the Harp (E) into the Saddle (C). Put the shade(F) on the Harp(E), then tighten the Finial (G)into the Harp (E), Insert the bulb(H) into the socket(D).

Step3: Put the light on a level surface to check if everything is stable.


Top Ring as this direction



Spider under the ring



SHADE



1. Carefully remove the coiled Lamp Shade from box and remove all plastic coverin.
2. Combine two sides of shade (J) together with velcro to extend it.
3. Hold the lamp shade (J) and push the Top ring (I) into the 5 metal buckles one by one, (Top ring as below direction).
4. Push the Bottom Ring (K) into the 5 metal buckles one by one until lock to the ring securely and form a shade.
5. Turn the Lamp Shade upright and gently adjust shape of the Lamp Shade.