


HOGYME

User Manual

Instruction for Assembly 4.2' * 9.1' Metal Shed



Missing Parts, Quality Problem, Questions on Assembly?
Email: Hogyme.service@gmail.com
Request will be replied in 24 hours.

Model Number: HG61R0646
HG61W0650
HG61B0654

HOGYME

Assembly Preparation

Owner's Manual

Please check local building codes regarding footings, location and other requirements before beginning construction.

Assembly instructions:

Reviewing all instructions and the appropriate information before you begin, make sure following the step sequence carefully for successful results.

Flooring base:

A good location for the storage building is a square and level area with good drainage. The base is not included in the kit which may need purchase separately or may construct a foundation and anchoring system of your own.

A strong plastic sheet (thickness: at least 150μm) should be placed under the foundation to assist in reducing rising dampness from the soil, thus reducing condensation build up in the shed. Your storage building must be anchored to prevent wind damage. Once secured, it is highly recommended applying silicone along the inside of the base rail to minimize condensation.


Parts and Parts List:

Before you start, separate and identify all the parts and hardware to be sure that you have all the necessary parts for your building (refer to the Parts List Page).

If you find that a part is missing, please notify the seller within one week after receiving the product. Do not attempt to assemble the building if parts are missing because any building left partially assembled may be seriously damaged by light winds.

Tools you need:

(Please tear off the safety protection layer before the assembly, keep the part number label if needed)




Safety must be put in the No. 1 position:

1. Select a dry and calm day for your assembly. Team works (Two or more people) are required during the assembly. It is also recommended to finish the assembly in a day to avoid damage to the product or missing of some small parts.
2. Wearing safety gloves, eye protection and long sleeves during the assembly to prevent injury. Pay attention to the sharp edge of some parts.
3. Children and pets are not allowed entering into the construction site.
4. Never concentrate your total weight on the roof of the building.
When using a step ladder make sure that it is safe.

Care & Maintenance:

1. Keep the shed clean with soft cloth, use water if necessary.
2. Keep the door tracks clear of dirt and other stuff that prevent them from sliding easily.
3. Clean the snow with necessary tools to make sure it is safe to enter into.
4. The shed is not made for living but storing stuff.
5. Please add some oil on the top and bottom door sliding channel to make door slides smoothly.


Size:




Area of installation requirement:




TOP2




TOP1




MIDDLE





DOOR













UNDER





Hardware List

NO.	IMAGE	MM	QTY	Box No.
UNDER				
Bm-B1		1366	X1	2/2
Bm-B2		1372	X1	2/2
Bs-A3		1166	X2	2/2
Bm-B4		932	X1	2/2
Bm-B5		932	X1	2/2
Bs-A6		916	X1	2/2
MIDDLE				
Bm-A7		1550	X10	1/2
Bm-A7b		1550	X2	1/2
Bs-A18		1078	X1	2/2

Bm-8		1550	X4	2/2
Bm-16		1550	X1	2/2
Bm-17		1550	X1	2/2
Bn-B11		1324	X1	2/2
Bn-B12		1324	X1	2/2
Bn-A13		1166	X1	2/2
Bn-A14		1166	X1	2/2
Bm-B9		1304	X1	2/2
Bm-B10		1304	X1	2/2
TOP1				
Bn-B19b		1325	X1	2/2
Bn-B19c		1325	X1	2/2
Bs-B28		1372	X1	2/2
Bs-B28a		1372	X1	2/2
Bn-A40		540	X1	2/2
Bn-A21b		1215	X1	2/2
Bn-A21c		1215	X1	2/2

T-X29		85	X3	2/2
Bn-A56		195	X8	2/2
TOP2				
Bn-A23		1320	X1	1/2
Bn-A24		1320	X7	1/2
Bn-A25		1320	X1	1/2
Bn-A26		1320	X1	2/2
Bn-A26a		1320	X1	2/2
Bm-B38		490	X1	2/2
Bm-B38a		1490	X1	2/2
Bm-39		1280	X2	2/2
DOOR				
Bm-A30		1538	X1	2/2
Bm-A35		1538	X1	2/2
Bm-A31		1535	X2	2/2
Bm-A32		495	X4	2/2
Bs-A33		424	X2	2/2


Bs-A34		424	X2	2/2
Bs-A36		1130	X2	2/2
Bs-A37		1130	X2	2/2
ANNEX				
T-P1			X4	2/2
T-P2			X4	2/2
T-P3			X4	2/2
T-P5A			X2	2/2
T-P6			X2	2/2
T-P7		150	X1	2/2
F1		st4X10	X285	2/2
F2		M4X10	X95	2/2
F3		st5X1	X8	2/2
S1			X107	2/2
S2			X210	2/2
V-A3		751	X4	2/2
V-A2		1336	X4	2/2

PRODUCT ASSEMBLY

 Check the package contents before getting started !

STEP 1


Bm-B1		X1	Bm-B2		X1
F1		X4			



PRODUCT ASSEMBLY

STEP 2


Bs-A3		X1	F1		X2
-------	---	----	----	---	----



PRODUCT ASSEMBLY

STEP 3


Bs-A3		X1	F1		X2
-------	---	----	----	---	----



PRODUCT ASSEMBLY

STEP 4

Bm-B4		X1	Bm-B5		X1
F1		X4			




PRODUCT ASSEMBLY

STEP 5

Bs-A6		}	X1	F1		X4
-------	---	---	----	----	---	----



The floor frame must be level and square or holes will not align.
(Notice: Measure the floor frame diagonally. When the diagonal measurements are equal, the floor frame is square.)




PRODUCT ASSEMBLY



Make the colored side of the steel plate outward.

STEP 6


Bm-8		X1	F1		X3
S2		X3			



PRODUCT ASSEMBLY

STEP 7


Bm-A7		X1	F1		X4
F2		X1	S2		X4



PRODUCT ASSEMBLY

STEP 8


Bm-8		X1	F1		X3
S2		X3			



PRODUCT ASSEMBLY

STEP 9


Bm-A7		X1	F1		X4
F2		X1	S2		X4



PRODUCT ASSEMBLY

STEP 10


Bm-8		X1	F1		X3
S2		X3			



PRODUCT ASSEMBLY

STEP 11


Bm-A7		X1	F1		X4
F2		X1	S2		X4



PRODUCT ASSEMBLY

STEP 12


Bm-8		X1	F1		X3
S2		X3			



PRODUCT ASSEMBLY

STEP 13

Bm-A7		X1	F1		X4
F2		X1	S2		X4




PRODUCT ASSEMBLY

STEP 14

Bn-A13		X1	F1		X6
S2		X6			



Put the side with fewer holes facing up.




PRODUCT ASSEMBLY

STEP 15

Bn-A14		X1	F1		X6
S2		X6			

 Put the side with fewer holes facing up.




PRODUCT ASSEMBLY

STEP 16

Bn-B11		X1	Bn-B12		X1
F1		X1			



 Put the side with fewer holes facing up.



PRODUCT ASSEMBLY

STEP 17


F1		X8	S2		X8
----	---	----	----	---	----



PRODUCT ASSEMBLY


STEP 18


Bm-B9		X1	Bm-B10		X1
T-P7		X1			



PRODUCT ASSEMBLY

STEP 19


Bs-A18		X1	F1		X2
--------	---	----	----	---	----



PRODUCT ASSEMBLY

STEP 20


F1		X8	S2		X8
----	---	----	----	---	----



PRODUCT ASSEMBLY

STEP 21


Bm-A7		X1	F1		X10
F2		X2	S2		X10



PRODUCT ASSEMBLY

STEP 22


Bm-A7		X1	F1		X10
F2		X2	S2		X10



PRODUCT ASSEMBLY

STEP 23


Bm-A7		X3	F1		X24
F2		X3	S2		X24



PRODUCT ASSEMBLY

STEP 24


Bm-A7		X1	F1		X10
F2		X2	S2		X10



PRODUCT ASSEMBLY



STEP 25


Bm-A7b		X2	F1		X16
F2		X2	S2		X16



PRODUCT ASSEMBLY



STEP 26


Bm-16		X1	Bm-17		X1
F1		X10	S2		X10



PRODUCT ASSEMBLY


STEP 27


Bn-B19b		X1	Bn-B19c		X1
T-P5A		X2	F2		X4



PRODUCT ASSEMBLY

STEP 28


Bn-A56		X8	F2		X16
--------	---	----	----	---	-----



PRODUCT ASSEMBLY

STEP 29


F2		X2
----	---	----



PRODUCT ASSEMBLY



STEP 30


F1		X10
----	---	-----



PRODUCT ASSEMBLY


STEP 31


Bn-A21b		X1	Bn-A21c		X1
F1		X10	F2		X6



PRODUCT ASSEMBLY



STEP 32

T-X29		X2	F2		X4
-------	---	----	----	---	----




PRODUCT ASSEMBLY

STEP 33

Bs-B28		X1	Bs-B28a		X1
T-X29		X1	F2		X4



The side with holes should be face-up.




PRODUCT ASSEMBLY

STEP 34

F2		X4
----	---	----




Please install by the number order shown in the step 33, or the holes in the roof panel cannot be aligned.



PRODUCT ASSEMBLY

STEP 35

Bn-A56		X1	F2		X2
--------	---	----	----	---	----




PRODUCT ASSEMBLY



Screws on the top panel can't be fixed too tightly in the beginning, and they can only be tightened after all holes are aligned.

STEP 36


Bn-A23		X1	F1		X6
S2		X6			



PRODUCT ASSEMBLY

STEP 37


Bn-A24		X7	F1		X56
S2		X42			



PRODUCT ASSEMBLY

STEP 38


Bn-A25		X1	F1		X8
S2		X6			



PRODUCT ASSEMBLY

STEP 39


Bn-B38		X1	Bn-B38a		X1
Bn-39		X2	F1		X16
S2		X16			



PRODUCT ASSEMBLY

STEP 40


Bn-A26		X1	Bn-A26a		X1
F1		X4	S2		X4



PRODUCT ASSEMBLY






STEP 41


T-P3		X4	F1		X4
------	---	----	----	---	----



PRODUCT ASSEMBLY

STEP 42


BmA35		X1	Bm-A31		X1
Bm-A32		X1	Bs-A36		X1
Bs-A37		X1	F2		X3



PRODUCT ASSEMBLY


STEP 43


T-P1		X2	F2		X4
------	---	----	----	---	----



PRODUCT ASSEMBLY

STEP 44


Bs-A33		X1	T-P6		X1
F2		X3			



PRODUCT ASSEMBLY

STEP 45


Bm-A32		X1	Bs-A34		X1
F2		X5			



PRODUCT ASSEMBLY



STEP 46


F2		X4
----	---	----



PRODUCT ASSEMBLY

STEP 47


BmA30		X1	Bm-A31		X1
Bm-A32		X1	Bs-A36		X1
Bs-A37		X1	F2		X3



PRODUCT ASSEMBLY

STEP 48


T-P1		X2	F2		X4
------	---	----	----	---	----



PRODUCT ASSEMBLY



STEP 49


Bs-A34		X1	T-P6		X1
F2		X3			



PRODUCT ASSEMBLY

STEP 50


Bm-A32		X1	Bs-A33		X1
F2		X5			



PRODUCT ASSEMBLY

STEP 51



F2		X4
----	---	----



PRODUCT ASSEMBLY

STEP 52


F3		X8
----	---	----



PRODUCT ASSEMBLY

STEP 53

V-A2		X4	V-A3		X4
F1		X16			



PRODUCT ASSEMBLY

STEP 54

S1		X107
----	---	------

