


Item # 967003

JASPER 4PC SEATING ASSEMBLY INSTRUCTIONS




ATTACH YOUR RECEIPT HERE

Order Number	Purchase Date	



Questions, problems, missing parts? Before returning to your retailer, email our customer service department directly at HELLO@LEISUREMADE.COM or call us at (888) 682-3012 8am-4pm EST, Monday-Friday.



Note: You will also have 4 plastic bags containing your fabric covers.

4 Bags: Standard Seat Covers (1 bag contains both 1 bottom seat and 1 back cover)

G

Н

٧

W

Table Leg

Table Top

Standard Seat Bottom

Standard Back Cushion


2

1

4

4

HARDWARE CONTENTS





SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate or install the product.



A CAUTION: Assemble on a soft, non-abrasive surface.

PREPARATION


Before beginning assembly of product, make sure all parts are present. Compare parts with the package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

If you find a missing or damaged part, please look through all pieces to make sure nothing else is missing or damaged. Compile a comprehensive list and give us a call. We will send out all parts in a single shipment. Ensuring you have all missing parts identified at the time you call will ensure a faster delivery to complete your beautiful patio furniture.

Please call us directly, not your retailer. As the manufacturer we can walk you through any issues you may have. We are here to help: (888) 682-3012

Before beginning, make sure all cushions and covers are present. Make sure you have identified the difference in the seat bottoms and seat backs before pulling on the fabric covers.


PART	DESCRIPTION	QTY
V	Standard Seat Bottom	4
W	Standard Back Cushion	4




HELPFUL TIP: we call this the 'Taco Method'.

Place the cushion between your knees and squeeze together to form a taco. This makes it much easier to pull on the cushion cover.


Place chair bench (A) face down on a soft surface and fasten the chair arms (B&C) to the chair with the bolts (AA), (BB) and washers (EE) using the allen key (GG).




With the chair still facing down on the ground, attach the cross bar (D) to the arms (B&C) using the bolts (CC) through the washers (EE).




Place loveseat bench (E) face down on a soft surface and fasten the chair arms (B&C) to the chair with the bolts (AA), (BB) and washers (EE) using the allen key (GG).



With the chair still facing down on the ground, attach the cross bar (F) to the arms (B&C) using the bolts (CC) through the washers (EE).



Place table top (H) face down on a soft surface and fasten the legs (G) to the top with bolts (DD) and washers (EE) using allen key (GG).



6. Flip coffee table over and add the cushions on it. Enjoy your beautiful furniture! If you have any issues please call (888) 682-3012 directly.

