

---

# **11 FT X 11 FT STEEL BUTTERFLY GAZEBO**

MODEL #TPGAZ2002

**TABLE OF CONTENTS**

---

Package Contents - Rafters, Beams and Canopy ..... 3

Package Contents - Posts and Balls..... 4

Hardware Contents ..... 5

Preassembly Instructions - Rafters ..... 6

Preassembly Instructions - Posts ..... 7


Assembly Instructions..... 8

Safety Information ..... 11

Care and Maintenance .....11

One-Year Limited Warranty .....11

## PACKAGE CONTENTS - RAFTERS BEAMS AND CANOPY




PART	DESCRIPTION	QUANTITY
<b>B</b>	Lintel	<b>8</b>
<b>C</b>	Angle head	<b>4</b>
<b>D</b>	Top support bar	<b>4</b>

PART	DESCRIPTION	QUANTITY
<b>E</b>	Center connector	<b>1</b>
<b>G</b>	Fabric	<b>1</b>

**PACKAGE CONTENTS - POSTS AND BRACES**

---



PART DESCRIPTION QUANTITY		
A	Post	4
F	Ball	4

## HARDWARE CONTENTS


---

**H**




Elastic Button  
Qty.32

**I**




Handle Screw  
Qty.8

**J**




Ring Screw  
Qty.4

**K**




Coupling Hook  
Qty.4

**L**





Stake  
Qty. 12


## PREASSEMBLY INSTRUCTIONS - RAFTERS




1. Put the lintel (B) together, insert one lintel (B) into angle head (C), take another lintel (B) and insert it into the other end of the lintel. Connect the rest of lintel (B) with angle head (C) in the same way.




## PREASSEMBLY INSTRUCTIONS- POSTS



2. Connect the little ball (H) to the top of the post (A) directly.



3. Fasten the ring screw (J) onto the post (A) directly.




### Hardware Used


**J** Ring Screw  **x4**

## ASSEMBLY INSTRUCTIONS

4. Insert the connected lintel into the post (A), and fix it with the handle screw (I).


### Hardware Used

**I** Handle Screw  x8







## ASSEMBLY INSTRUCTIONS



5. Insert the end of one top support bar (D) into central connector (E), insert the other end into angle head (C), in the same way, insert the another three top support bars (D) into three more angle heads (C).




## ASSEMBLY INSTRUCTIONS

6. Put the fabric (G) on the top of gazebo and fix it on the lintel (B) with the elastic button (H) through top covered fold, then with one end of the coupling hook (K) through the corner of the fabric (G), connect the other end to the ring screw.

### Hardware Used


**H** Elastic Button  x32


**K** Coupling Hook  x4



7. Insert the stake (L) into the ground through the base plate to secure the gazebo.

### Hardware Used

**L** Stake  x12





## **SAFETY INFORMATION**

---

Please read and understand this entire manual before attempting to assemble, operate or install the product.



### **WARNING**

- Assemble the item on a soft, non-abrasive surface, such as carpeting, to avoid damage.
- This item is heavy. Use care when handling.
- Use four adults to ensure safe assembly.

### **CAUTION**

**DO NOT** leave out during high winds, heavy rains or snow. Remove the canopy

## **CARE AND MAINTENANCE**

---

Wash with mild soap. Rinse with water and let air dry.

### **CAUTION**

**DO NOT** leave out during high winds, heavy rains or snow. Remove the canopy

## **ONE-YEAR LIMITED WARRANTY**

---

This warranty is extended to the original purchaser and applies to defects in materials and workmanship of your patio furniture provided your furniture is maintained with care and used only for personal, residential purposes.

Frames are warranted to be free from defects in material or workmanship for a period of one (1) year.

Exclusions: Items used for commercial, contract or other non-residential purposes; display models; items purchased "as is;" or items damaged due to acts of nature, vandalism, misuse or improper assembly are not covered. Discoloration or fading of the finish or fabrics as a result of exposure to the elements, chemicals or spills is not covered. Tabletop breakage, corrosion or rusting of hardware and damage to frames or welds caused by improper assembly, misuse or natural causes are not covered.

Warranty is to the original purchaser and is non-transferable. Any replacement of warranted items will be in the original style and color or a similar style and color if the original is unavailable or has been discontinued. As some states do not allow exclusions or limitations on an implied warranty, the above exclusions and limitations may not apply. This warranty gives you specific rights, and you may also have other rights which vary from state to state.

If you come across any issue, please contact Below email for after sale service, We will provide support at any time. E-mail: [service@taipengchina.com](mailto:service@taipengchina.com)