



Artificial Holiday Christmas Tree

Before You Start



EN



WARNING - Risk of Fire and Electric Shock:

1. Read all instructions and warning tags included with this tree.
 2. Do not place near barbeques, candles, outdoor heaters, or other similar sources of heat.
 3. Do not install near pools, fountains, tubs, sinks, or other areas of standing water that the tree may fall or blow into.
 4. Disconnect tree's light sets from power before starting.
 5. Keep wires clear of being pinched or cut during assembly or installation.
- Discard sets with cut or pinched insulation.
6. Do not press or grasp bulbs during assembly or installation.
 7. Make sure final assembly stable enough to hold the tree upright.
 8. Do not use candles on tree. Use only with the included mini lights.
 9. Do not overload extension cords or power strips.
 10. Always fully insert electrical plugs into a receptacle.
 11. This product is for decoration use only. Not to be used by children as a toy.

Keep out of reach of small children.

No tools required for assembly.

Before You Start

1. Decide on an appropriate location for your product, please read assembly and

Instruction Procedure carefully.

2. Retain the instructions for future use and save the carton for storing your tree.

EN









- ⚠ Please read all instructions carefully.
- ⚠ Retain instructions for future reference.
- ⚠ Separate and count all parts and hardware.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Always place the product on a flat, steady and stable surface.
- ⚠ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.

Installation instructions



 INSTRUCTION	 APPROXIMATELY 15-25 MIN. ASSEMBLY
 5-6FT 1 PERSON ASSEMBLY	 7-8FT 2 PERSON ASSEMBLY
 CAP	NOTE: Please remove the circular protector caps on the end of each pole before assembling.

A  TOP SECTION	B  MIDDLE SECTION	
C  MIDDLE SECTION 2	D  BOTTOM SECTION	
E  TREE BASE x1 + SCREWS x3	F  LED LIGHT STRING (ALREADY WRAPED ON THE TREE)	G  TRANSFORMER

We will divide the tree into different sections according to the shape and size of the tree.

Usually: 5ft: A+D+E+F+G, 6ft-7ft: A+B+D+E+F+G, 7ft-8ft: A+B+C+D+E+F+G.

Assembly and Instruction Procedure:



Every carton should contain a top section and a bottom section (larger trees include middle sections).

This will depend on what model you have purchased. Also included is a metal base .

Remove all Packaging (i.e. cardboard or plastic) before beginning.

1. Choose a location where the tree is to be displayed. Take out the tree stand.

Metal stand unfolds as “X” shaped as Figure1, place it on a flat surface.

2. Insert the pole with tapered end of the tree bottom into the tree stand and tighten the 3 screws on the stand.

3. Insert the middle tree section into the tree bottom and push down into position.

(Note: This does not apply to trees with only A+D)

4. Insert the tree top into the middle tree section and push down into position.


5. CONNECTING THE STRINGS WITH POWER:

Please find the power supply cord on the bottom Section. If there is no power supply cord, follow the method below: Carefully connect the plug to end-connector by A to A, and B to B.

6. Gently lower all main branches on tree sections. Take care not to place unnecessary pressure on the brackets when assembling. The branches on your tree can be adjusted to give tree the desired amount of fullness. For best results, straighten and separate all branch tips, then bend them slightly upward.


1

Make the innermost tips to be 90° to the branch and between-tips 45°




2

Make the next layer tips to be 60° to the branch and between-tips 45°




3

Make the next layer tips to be 45° to the branch and between-tips 45°




4

Make the outerm to be 5 direction picture, the top or 180° to the branch



7. Plug tree lights into a power outlet.

YOUR TREE IS NOW READY TO ENJOY!



Storage Tips:

1. Warning - Disconnect power from the lights.
2. Remove all decorations.
3. Starting from the top, carefully remove branches. Press the tips back up against the stem.
4. Place the branch sections back into the carton, putting the longest one on the bottom.
5. Store the product in a cool, dry location protected from sunlight, where the temperature does not exceed 40°.

EN




Return / Damage Claim Instructions

-  **DO NOT discard the box / original packaging.**
In case a return is required, the item must be returned in original box. Without this your return will not be accepted.
-  **Take a photo of the box markings.**
A photo of the markings (text) on the side of the box is required in case a part is needed for replacement. This helps our staff identify your product number to ensure you receive the correct parts.
-  **Take a photo of the damaged part (if applicable).**
A photo of the damage is always required to file a claim and get your replacement or refund processed quickly. Please make sure you have the box even if it is damaged.
-  **Send us an email with the images requested.**
Email us directly from marketplace where your item was purchased with the attached images and a description of your claim.


Scan this QR code to download
the Control Center APP




1.Choose your region and download this app.



2.Click on "ALL Devices" in "HOME"
to add devices.



3.To connect to WIFI,press and hold the
controller button for 4 second until the
greenindicator light flashesquickly.



4.Enter the control interface and DIY
the colorful lights according to
the instructions.

