

Musical Figurine Assembly Instructions

The model number of your figurine is printed on the side of your carton.
Always use this number to identify your model.

Thank you for your purchase of this quality holiday decoration. With proper use and care, your figurine will provide you with years of enjoyment. Please follow the instructions on how to assemble and disassemble.

If you should have any problem with your decoration, DO NOT return it to the place of purchase. Please call our toll free number below and a customer service representative will assist you. Enjoy your holiday!

Customer Service: 1-855-591-7451 (9am to 5pm, Monday through Friday)

Your Package Includes:


1 Figurine & 1 Transformer

This product is for indoor use only. Do not place in direct sunlight.
This product operates with 12V isolating transformer. Only use with 12V transformer supplied.

This product requires 3 AA batteries. Batteries not included.

Please read all instructions completely before assembling your figurine.

5. Remove all parts from packaging carefully. **Use caution with sharp tools**
6. Stand figurine body upright on sturdy surface.
7. Straighten out the clothes and fluff up any accessories.
8. Insert the transformer into the power socket and switch to ON. The ON and OFF switch is located on the white platform by the feet.
1. Insert the large end of the cable into the transformer and gently tighten the nut and socket.
2. Insert the smaller end of the cable into the jack that is on the rear end, behind the back of right hand.
3. Straighten out the clothes and fluff up the beard.
4. Insert the transformer into the power socket and switch to ON. The ON and OFF switch is located on the white platform by the feet.





Warnings

1. This product is for decoration only and is not a toy. Please keep out of reach of small children.
2. Do not position the figurine near candles, sources of heat, or in direct sunlight.
3. The figurine cannot be connected to the power supply directly.
4. Do not break, cut, or alter the power cable.
5. Do not attempt to repair the wiring with staples or nails.
6. Do not place the cable under a carpet or rug as it may get damaged.
7. Ensure that the cable is in a secure location where it is not a hazard.
8. Do not connect the figurine to the power supply while it is still in the packaging.
9. Please switch off the transformer when not in use.
10. Do not leave figurine unattended while operating in the ON position.
11. Do not over load the transformer.
12. Figurine should be on a level, stable surface to prevent it from falling over

Storage tips: We suggest to save the carton for storing your figurine. Store in a cool, dry area where the temperature does not exceed 100°F.