Patio Furniture – Use & Care Manual

Thank you for choosing Teamson Patio Furniture. Designed for comfort, relaxation, and style, your patio furniture will enhance your outdoor space for years to come. Please follow the guidelines below to ensure proper use and long-lasting care.

General Use & Setup Tips

- **Solution Assembly Required:** Follow the included instructions carefully for assembly. Ensure all parts are properly secured before use.
- **A** Level Surface: Always place your patio furniture on a flat, stable surface to avoid tipping or instability.
- Avoid Overloading: Do not exceed the recommended weight limits. This will help preserve the structure and longevity of the furniture.
- Outdoor Placement: Place furniture in a well-ventilated area, away from direct sunlight and extreme weather to prevent damage.
- **Use Protective Covers:** When not in use, protect your patio furniture with covers to shield it from dirt, debris, and harsh weather conditions.

Care & Cleaning Guidelines

- *e* Cushions & Upholstery:
 - Spot Clean: Regularly wipe down cushions with a soft cloth to remove dirt and spills. For deeper cleaning, use a mild detergent and water.
 - Dry Thoroughly: After cleaning, allow cushions to air dry completely before use to prevent mold and mildew.
 - **Storage:** If possible, store cushions indoors or in a dry, sheltered area during the off-season or heavy weather.

• 🧶 Metal Frame & Finishes:

 A Routine Dusting: Dust the metal frames regularly with a soft cloth or microfiber duster to remove dirt and prevent buildup.

- Cleaning: Clean metal parts with a soft cloth and a mild soapwater solution. Avoid abrasive cleaners that can scratch the surface.
- Rust Prevention: To minimize rust, apply a protective metal spray or polish annually.
- Check for Damage: Inspect metal parts for signs of rust, corrosion, or wear. Repair or replace as needed.
- 🔺 Wooden Parts:
 - Clean with Care: Wipe wooden surfaces with a damp cloth and mild soap solution. Always follow the grain of the wood to avoid damage.
 - Seal Regularly: Apply a wood sealer or protective finish annually to maintain its natural look and protect against weathering.
 - **Check for Cracks:** Regularly inspect wooden furniture for cracks or damage. Sand down rough patches and refinish if necessary.

Safe Operation

- Supervised Use: Always ensure that children and pets are supervised while using patio furniture to avoid accidents.
- **O** Avoid Dragging: When moving your furniture, lift it instead of dragging it to prevent damage to both the furniture and your flooring or deck.
- A Use Proper Seating: Only sit on the furniture as intended and avoid standing or jumping on it.

Maintenance Tips

- **Storage:** During the off-season, store your patio furniture in a dry, sheltered area or use furniture covers to protect it from harsh weather.
- Seasonal Cleaning: Before the first use each season, perform a thorough cleaning to remove any dirt, debris, or mildew that may have accumulated during storage.
- 🔧 Inspect Regularly: Periodically check for any loose bolts, cracks, or other

issues. Tighten loose screws or bolts to maintain stability.

Environment & Seasonal Care

- **Moisture Control:** If storing furniture in a damp area, use moistureabsorbing products (such as silica gel packets) to prevent mold or rust.
- **Temperature Sensitivity:** Extreme temperature fluctuations can affect the material. Store your furniture in a cool, dry location when not in use.
- Sun Exposure: Prolonged exposure to direct sunlight can cause fading or damage. Consider using a UV-resistant cover or storing furniture during the hottest months.

Thank you again for choosing Teamson Patio Furniture. We are committed to providing you with high-quality products that enhance your outdoor living space. We hope this manual helps you keep your patio furniture in top condition for years to come. If you have any further questions or need assistance, please don't hesitate to reach out to our customer service team.