

Safety Information

1. Caution! If you feel uncomfortable tingling heat or if the skin turns red, there is a risk of burns. Turn off the device immediately and stop use immediately. Read the safety information carefully before first use.
2. Do not allow water to collect or pool on the chair. Chair should be completely dry before attaching battery and powering on.
3. Heating elements should not be allowed to touch bare skin.
4. Shut off power immediately if discomfort occurs.
5. Do not allow the wires in the product to be pinched.
6. Discontinue use of this product if it stops working correctly or heats inconsistently.
7. Do not use pins or sharp objects around this jacket as they can cause damage to wiring.
8. Remove the battery pack from the battery pocket before washing. Spot clean only.
9. Do not dry clean. Do not use dry-cleaning fluid on this item. Do not bleach. Cleaning solvents may have a detrimental effect on the insulation of the heating elements.
10. Do not iron.
11. Do not use if you have impaired temperature sensitivity. Consult with your doctor before use.
12. Keep the product out of the reach of children, as it contains small parts which could be easily swallowed.
13. Always turn off the device and disconnect the batteries when it is not in use.
14. This item should be serviced by a qualified repair person using only identical replacement parts.



USER INSTRUCTION

Heated Director's Chair



How to heat



01

Locate the battery pocket on the back of the chair. Attach the battery (Battery not included in our package, you need to buy somewhere) to the cable found inside the pocket, place the battery inside the pocket, then zip the pocket closed.



02

Press and hold the button for 2s until the red light turns on (red light is High Heat). Click the button to switch the temperature level. Blue light is medium heat, green light is low heat. When not in use, long press 2s to turn off.



03

The chair has two heating zones and comes with a USB cable for heating the back and heating the bottom.

How to Store and Carry



Grasp the sides of the chair base with both hands and press inward.




You can carry it anywhere on your back.

How To Activate Heater Function


generally does not include mobile power according to purchase options

- 1 Plug USB cord into a battery pack. *** Without battery**
- 2 Press and hold the power button for three seconds to turn on the heater.
- 3 There are one heating options in the seat. Press the button to heat the back and the bottom.




Circular button


- 4 There are three heating modes in the seat. Press the power button repeatedly to change to another heat setting indicated by the colours.



Red - High heat



Blue - High heat



Green - High heat

Universal mobile power supply available (5V2A specification, power greater than or equal to 10W) battery capacity of 10000, 20000mAh, etc