



## PLEASE DO NOT RETURN TO THE STORE!

Missing or damaged parts? Contact us for free replacements and get an extra 6-month warranty.

E-mail: Nicesure-aftersales@outlook.com.

## ASSEMBLY INSTRUCTION:

### 1.Initial Tightening

Use a hex key (Allen wrench), not a power drill, to tighten each screw to about 50% before fully securing any of them. Fully tightening one screw too early may cause others to misalign.

### 2.Final Tightening

Once all parts are aligned, gradually and evenly tighten all screws using the proper tools.

### 3.Misalignment Fix

If some screws don't line up, loosen all screws to 50%, adjust the parts, and try again.

### 4.Stability Issue


If the item feels unstable, loosen all screws, adjust it on a flat surface, then retighten them evenly.

## Hardware Fittings

| Item No. | Reference Image                                                                     | Description          | Qty. | Extra Spare Parts Qty. |
|----------|-------------------------------------------------------------------------------------|----------------------|------|------------------------|
| A        |    | screw M8*35          | 4    | 1                      |
| B        |    | screw M8*30          | 11   | 1                      |
| C        |   | spring washer for M8 | 15   | 1                      |
| D        |  | nut for M8           | 15   | 1                      |
| E        |  | washer for M8        | 15   | 1                      |
| F        |  | Screw cap            | 15   | 1                      |

| Item No. | Reference Image                                                                     | Description          | Qty. | Extra Spare Parts Qty. |
|----------|-------------------------------------------------------------------------------------|----------------------|------|------------------------|
| G        |   | Adjustable foot pads | 4    | 1                      |
| H        |   | allen key for M8     | 1    | 0                      |
| I        |  | Spanner for M8       | 1    | 0                      |
| J        |                                                                                     |                      |      |                        |
| K        |                                                                                     |                      |      |                        |
| L        |                                                                                     |                      |      |                        |


### Step1



### Step2



### Step3





## PLEASE DO NOT RETURN TO THE STORE!

Missing or damaged parts? Contact us for free replacements and get an extra 6-month warranty.

E-mail: Nicesure-aftersales@outlook.com.

## ASSEMBLY INSTRUCTION:

### 1.Initial Tightening

Use a hex key (Allen wrench), not a power drill, to tighten each screw to about 50% before fully securing any of them. Fully tightening one screw too early may cause others to misalign.

### 2.Final Tightening

Once all parts are aligned, gradually and evenly tighten all screws using the proper tools.

### 3.Misalignment Fix

If some screws don't line up, loosen all screws to 50%, adjust the parts, and try again.

### 4.Stability Issue


If the item feels unstable, loosen all screws, adjust it on a flat surface, then retighten them evenly.

## Hardware Fittings

| Item No. | Reference Image                                                                     | Description          | Qty. | Extra Spare Parts Qty. |
|----------|-------------------------------------------------------------------------------------|----------------------|------|------------------------|
| A        |    | screw M8*35          | 12   | 1                      |
| B        |    | washer for M8        | 12   | 1                      |
| C        |   | spring washer for M8 | 12   | 1                      |
| D        |  | nut for M8           | 12   | 1                      |
| E        |  | Screw cap            | 12   | 1                      |
| F        |  | Adjustable foot pads | 4    | 1                      |

| Item No. | Reference Image                                                                    | Description      | Qty. | Extra Spare Parts Qty. |
|----------|------------------------------------------------------------------------------------|------------------|------|------------------------|
| G        |  | allen key for M8 | 1    | 0                      |
| H        |  | Spanner for M8   | 1    | 0                      |
| I        |                                                                                    |                  |      |                        |
| J        |                                                                                    |                  |      |                        |
| K        |                                                                                    |                  |      |                        |
| L        |                                                                                    |                  |      |                        |

### Step1



### Step2

