


ASSEMBLY INSTRUCTION


DINING TABLE









WF324180


IMPORTANT NOTE :

- ① PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- ② BEFORE YOU BEGIN , KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- ③ DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE TABLE IS FULLY SET-UP




PART LIST		HARDWARE LIST	
①		Ⓐ	 Ø5/16" x 65mm BOLT (8pcs)
		Ⓑ	 Ø5/16" x 55mm BOLT (2pcs)
②		Ⓒ	 Ø5/16" x 35mm BOLT (20pcs)
		Ⓓ	  Ø1/4" x 110mm BOLT (4pcs)
③		Ⓔ	 Ø5/16"x13mm SPRING WASHER (8pcs)
		Ⓕ	 Ø5/16"x19mm FLAT WASHER (8pcs)
④		Ⓖ	 Ø10 x 40mm WOODEN PEGS (16pcs)
		Ⓗ	 4x58mm ALLENKEY (1pc)
⑤		Ⓘ	 28x15x7mm FLAT WASHER (2pcs)
⑥			
⑦			
STRETCHER (1pc)			

Step 1




G	Ø10x40		8PCS			
A	Ø5/16"x65		8PCS	F	Ø5/16"x19	 8PCS
E	Ø5/16"x13		8PCS	H	4x58	 1PC

Step 2




C	Ø5/16"x35		8PCS	H	4x58		1PC
----------	-----------	---	------	----------	------	---	-----

Step 3



			I	28x15x7mm 	2PCS
D	Ø1/4"x110 	4PCS	G	Ø10x40 	8PCS
B	Ø5/16"x55 	2PCS	H	4x58 	1PC


Step 4



C	Ø5/16"x35 	12PCS	H	4x58		1PC
----------	---	-------	----------	------	---	-----

ASSEMBLY INSTRUCTION


DINING CHAIR









WF324181

IMPORTANT NOTE :



- ① PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- ② BEFORE YOU BEGIN , KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- ③ DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE CHAIR IS FULLY SET-UP




Part List For One Chair

8 	10 
	LEFT CHAIR LEG (1pc)
9 	11 
	RIGHT CHAIR LEG (1pc)
	12 
SEAT FRAME (1pc)	13 
	RIGHT STRETCHER (1pc)

Hardware List For One Chair


J	 Ø10 x 30mm	N	 Ø1/4" x 13mm
	WOODEN PEGS (1pc)		SPRING WASHER (10pcs)
K	 Ø1/4" x 75mm	O	 Ø1/4" x 19mm
	BOLT (4pcs)		FLAT WASHER (10pcs)
L	 Ø1/4" x 55mm	P	 Ø4 x 38mm
	BOLT (4pcs)		SCREW (4pcs)
M	 Ø1/4" x 35mm	H	 4x58mm
	BOLT (2pcs)		ALLENKEY (1pc)

Step 1




J	Ø10x30 	1PC	N	Ø1/4"x13 	6PCS
K	Ø1/4"x75 	4PCS	O	Ø1/4"x19 	6PCS
M	Ø1/4"x35 	2PCS	H	4x58 	1PC

Step 2



				N	Ø1/4"x13		4PCS
				O	Ø1/4"x19		4PCS
L	1/4x55		4PCS	H	4x58		1PC


Step 3



P	Ø4x38		4PCS
----------	-------	---	------

ASSEMBLY INSTRUCTION


DINING BENCH



WF324182


IMPORTANT NOTE :

- ① PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- ② BEFORE YOU BEGIN , KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- ③ DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE BENCH IS FULLY SET-UP




PART LIST FOR ONE BENCH		HARDWARE LIST FOR ONE BENCH	
14		L	Ø1/4" x 55mm
		Q	Ø1/4" x 40mm
15		R	Ø8 x 30mm
		S	Ø15 x 15 x 2mm
16		T	Ø40 x 40 x 20mm
		U	Ø19"x15x10mm
17		V	Ø4 x 15mm
		H	4x58mm
18			
19			

ASSEMBLY TOOLS REQUIRED (NOT INCLUDED)




Step 1




R	Ø8x30		4PCS
----------	-------	---	------

Step 2




L	Ø1/4"x55		6PCS	U	19x15x10		6PCS
R	Ø8x30		12PCS	H	4x58		1PC

Step 3




T	40x20x20		4PCS	V	Ø4x15		16PCS
----------	----------	---	------	----------	-------	---	-------

Step 4



S	15x15x2		12PCS	V	Ø4x15		12PCS
----------	---------	---	-------	----------	-------	---	-------

Step 5





V

Ø4x15



12PCS

Step 6



Complete

Q	Ø1/4"x40 	4PCS	H	4x58		1PC
----------	--	------	----------	------	---	-----