


PATIOJOY



USER'S MANUAL

Folding Canopy OP70811

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first.

Replacements for missing or damaged parts will be shipped ASAP!

Follow Costway



Contact Us!

Do NOT return this item.

Contact our friendly customer service department for help first.



Before You Start

- ⚠ Please read all instructions carefully.
- ⚠ Retain instructions for future reference.
- ⚠ Separate and count all parts and hardware.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Always place the product on a flat, steady and stable surface.
- ⚠ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.

Welcome to visit our website and purchase our quality products!

With your inspiring rating, COSTWAY will be more consistent to offer you
EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!

US office: Fontana, California

UK office: Ipswich



- * Reward Points
- * Exclusive Customer Service
- * Personalized Recommendations
- * Permanent Shopping Cart
- * Order History

5 Star Rating



We would like to extend our heartfelt thanks to
all of our customers for taking time to assemble
this product and giving us valuable feedbacks.

THANK
YOU
😊


Take Down The Canopy

Step1

- Detach hook and loop straps from the top and curtains.


Step2

- Raise a leg off the ground and depress the snap button to disengage the lower leg. Repeat until all four legs have been lowered.




Step3

- Pull the ring on the slider at each corner bracket to disengage the frame and allow it to close.




Step4

- Remove elastic loops on the top from each eave extension corner.
- Stand opposite a partner and grasp the lower truss bar. Lift the frame off the ground and slowly walk toward partner being careful not to pinch fingers.




Step5

- Remove canopy top and completely close the frame. We recommend storing canopies without the top to avoid mildew and pinch tears.




Step6

- Store frame and top in roller bag.



Replacement

Part	Description
A	Awning rods
B	Ceiling assembly
C	Eave assembly
D	Awning arm
E	Leg assembly
F	Leg assembly
G	Canopy top
H	Wheeled Storage Bag
I	Stake
J	Guy Rope



IMPORTANT:

Carefully read and follow the instructions provided with this product.

WARNING:

Keep all flame and heat sources away from this canopy top and sidewall fabric. This canopy top is made with flame resistant fabric which meets CPAI-84 specification. It is NOT FIRE PROOF. The fabric will burn if left in continuous contact with any flame source. The application of any foreign substance to this fabric may render the flame resistant properties ineffective.

WARNING:

Do not set-up or leave the canopy unattended in the following conditions: gusty wind, rain, hail, sleet, snow, drizzle, or any other harsh weather conditions. Doing so may cause damage to the entire canopy and will void the warranty.

Set Up The Canopy


Step1

- Stand the Instant Canopy frame upright in the center of the desired set-up location.
- Stand opposite a partner and lift frame off the ground walking backwards away from partner.




Step2

- Turn up each thin pole which connect to the roof pole.
- Attach a small canopy top to the four thin pole to become a small roof.




Step3

- Place canopy top over partially opened frame.
- Align eave extension corners of the top and the frame then attach the elastic loops to each corner of the frame.




Step4

- Open frame completely
- Engage the slider at each corner by placing one hand on the truss, one hand on the top of the leg and pushing up until the pin "clicks" in place.




Step5

- Attach the hook and loop straps to each corner and overhead truss bars.




Step6

- Extend each inner leg to raise canopy to the desired height by stepping on the lower footpad and allowing the snap button to lock in place.



Step7

- Attach corner curtains to top truss bars (a) (b) & (c).



Step8

- Your Instant Canopy is now complete!

