Manual Transfer Interlock Kits

Prevents dangerous feedback between two sources of power.

	Catalog Number	Usage Information	Utility Main Breaker Type	Standby Main Breaker Type	Interlock Number
	ECSBPK01	For use on load centers or meter combinations that will accept 2-pole circuit breakers opposite one another as shown.	QР, QРН, НQРН	QP, QPH, НQPH	1
1000	ECSBPK02	For use on load centers or meter combinations that will accept 2- or 4-pole next to a 2-pole circuit breaker side by side as shown.	QР, QРН, НQРН	QP, QPH, HQPH	2
	ECSBPK03	For use on Ultimate [™] and Rock Solid load centers, 150 amp and higher, to connect the main breaker to a 2-pole circuit breaker.	MBK150A,MBK200A, OR MBK225A	QP, QPH, HQPH	3
	ECSBPK04	For use on Ultimate and Rock Solid load centers, 125 amp and lower, to connect the main breaker to a 2-pole circuit breaker.	MBK100A or MBK125A	QР, QРН, НQРН	4
	ECSBPK05	For use on load centers or meter meter combinations that will accept a QNR (MD-TR) frame circuit breaker next to a 2-pole circuit breaker as shown.	QNR, QNRH, HQNR	QР, QРН, НQРН	5
	ECSBPK06	For use on load centers or meter combinations that will accept a QN (MD-T) frame circuit breaker next to a 2-pole circuit breaker as shown.	QN, QNH, HQN	QР, QРН, НQРН	6
	ECSBPK07	For use on load centers or meter combinations that will accept two QNR (MD-TR) circuit breakers side by side as shown OR will accept two QN (MD-T) circuit breakers side by side as shown.	QNR, QNRH, HQNR, QN, QNH, HQN	QNR, QNRH, HQNR, QN, QNH, HQN	7
	ECSBPK08	For use on 8 space, over/under, OH/UG feed meter combinations as shown. Limited application to specific catalog numbers.	QPP, QPPH	QР, QРН, НQРН	8
77	ECSBPK09	For use on 20 space, over/under, OH/UG feed meter combinations as shown. Limited application to specific catalog numbers.	QPP, QPPH	QР, QРН, НQРН	9