USER MANUAL

XP709

Pro Power 2300L DS

USB
Rechargeable



FEATURES

- OLED Display
- Lockout
- Dual-power (3 AAA holder included)
- Focusing
- USB-C
- TACKGRIP®

ANSI/PLATO FL1 STANDARD

MODES	LUMENS	RUN TIME	BEAM DISTANCE
Turbo	2300 lm	45s	107
High	1209 lm	3H 45M	75
Medium	544 lm	6H 30M	43
Low	75 lm	13H	19

OPERATION INSTRUCTIONS

DEMO Mode: Initial charging required to permanently unlock flashlight from demo mode.
TO UNLOCK FROM LOCKOUT: Double press button

On/Off: Press and release button. Cycle through modes to Off, or press button when it not illuminated to go directly to Off.

CYCLE MODES: While illuminated, press button to change modes



CHARGING INSTRUCTIONS

Charging Instructions: To charge the flashlight, locate the USB-C port cover on the back of the light. Open the cover and insert the USB-C end of the charging cable into the port. Connect the other end of the cable to a 5V USB power source.

Battery Indicator: A blue light means the battery is above 30% charged. A red light indicates low power—charging is recommended.

The XP709 has a charge time of approximately 3 hours.

Using AAA Batteries: To switch power sources, unscrew the tail cap, remove the rechargeable battery, and insert 3 AAA batteries into the included battery holder. Place the holder into the flashlight with the arrow pointing downward, then securely screw the tail cap back on.

PRODUCT WARRANTY

The XP709 has a Limited Lifetime Warranty Against Manufacturer's Defects from time of purchase.
For warranty claims please contact us by calling 801-553-8886 or sending an email to info@luxpro.com

14725 S Porter Rockwell Blvd Ste C
Bluffdale, UT 84065