# ASSEMBLY INSTRUCTIONS



### **TOOLS REQUIRED**



Allen Wrench

(Included)



Phillips Screwdriver (Not Included)




2 - People Recommended

# **ASSEMBLY RATING**



EASY — DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



# PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





### **Teamwork**

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





#### **Suitable Location**

Assembling near the area of the intended location is highly recommended.





# **Sufficient Space**

Make sure you have enough space to move around during the assembly.





#### **Avoid Scratches**

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





#### **Flat Surface**

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

# ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

# COUNTER HEIGHT CHAIR



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



x2

### **PARTS**



1pc x2

) 1pc x2

1pc x2







**Backrest** 

Wooden Seat

Front Leg - Left (CL)

Front Leg - Right (CR)

1pc x2

1pc x2

1pc x2



Front Stretcher

Left Stretcher (CL)



Right Stretcher (CR)

# **HARDWARE**

(#A) 2pcs x2

4pcs x2

4pcs x2

#D) 10pcs x2



**JCBC BOLT** M6 x 35mm

JCBC BOLT M6 x 60mm

JCBC BOLT M6 x 80mm

M6 SPRING **WASHER** 

(#E) 10pcs x2

6pcs x2

#G) 1pc



<ammum(⊕)

M6 FLAT WASHER

**CSK SCREW** M4 x 38mm

**ALLEN WRENCH** 

# **ASSEMBLY INSTRUCTIONS**

DO NOT fully tighten all bolts and screws until assembly is completed.

1

Part (#1) x 1pc

Part (#2) x 1pc


Hardware (#A) x 2pcs

Hardware (#C) x 4pcs

Hardware (#D) x 6pcs

Hardware (#E) x 6pcs

Align seat (#2) to the chair back (#1). Secure corner holes by using bolts (#C) with washers (#D,E), then secure middle holes by using bolts (#A) with washers (#D,E).



2

Part (#3) x 1pc


Part (#4) x 1pc

Hardware (#B) x 4pcs

Hardware (#D) x 4pcs

Hardware (#E) x 4pcs

Align left/right front legs (#3,4) to the seat (#2), then secure by using bolts (#B) with washers (#D,E).



# **ASSEMBLY INSTRUCTIONS**

Align stretchers (#5,6,7) to the legs, then secure by using screws (#F).


3

Part (#5) x 1pc


Part (#6) x 1pc

Part (#7) x 1pc

Hardware (#F) x 6pcs



4



# **ASSEMBLY COMPLETED**



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

## ✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

### ✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.