

A101-054-001 Assembly Instructions



Important -Please read these instructions fully before starting assembly

HASSLE-FREE WARRANTY

We stand behind the quality of our products. For full warranty policy,email: poly@homeselecting.com




Components

If you need help or have damaged or missing parts, please email:poly@homeselecting.com

Please check you have all the components listed below.


Note: The ilustration of the product shows the exact position of each part. Check when assembling.



#	Description	Qty
Α	Back frame assembly	2
В	Bracket assembly	2
С	Left front foot	2
D	Right front foot	2
Е	Right hind foot	2
F	Left hind foot	2
G	Front gear	2
Н	Rear gear	2
J	Connect the front and back feet	4


Hardware & Tools

Note: The quantities below are the correct amount to complete the assembly. in some cases more fittings may be supplied than required.



Assembly Instructions If you need help or have damaged or missing parts, please email:poly@homeselecting.com

▲ Caution: Please do not over-tighten bolts and screws during assembly.



3 ×2 4 ×2

STEP 2


As shown in the figure,

Use 1 to fix E, H, F.

As shown in the figure, Use ③ ④ to fix F、A、E, Insert the tenon of parts H into the mortise of parts E and F.

Assembly Instructions If you need help or have damaged or missing parts, please email:poly@homeselecting.com

⚠ Caution: Please do not over-tighten bolts and screws during assembly.




STEP 3

STEP 4

As shown in the figure,


Use ② to fix C、D、B、E、F

As shown in the figure, Use ① to fix C、G、D.



⚠ Caution: Please do not over-tighten bolts and screws during assembly.

Assembly Instructions If you need help or have damaged or missing parts, poly@homeselecting.com



STEP 5

As shown in the figure, Use ① to fix D、B、C.

(2) ×8 STEP 6 As shown in the figure, Use ② to fix D、C、J、E、F. Your chair is ready for use.

- Clean the product with a solution of mild soap and water. Dip a soft cloth or sponge into the solution and wipe down the entire surface.
- After cleaning, thoroughly rinse the furniture with water to remove any remaining soap residue.
- lifespan.

The other chair is done in the same way.

Important -Please read these instructions fully before starting assembly

please email:poly@homeselecting.com

Warnings

Check you have all the components and tools listed Do not stand or put weight on the product, this could cause damage.

Remove all fittings from the plastic bags and separate them into their groups.

Keep children and animals away from the work area, small parts may cause choking if swallowed.

Make sure you have enough space to layout the parts before starting.


on the page 2.

Assemble on a soft level surface to avoid damaging the unit or your floor.

If you need help or have damaged or missing parts,

Assemble the item as close to its final position (in the same area) as possible.

Do not place furniture directly in front of radiators, fires, or any other source of heat.



with 2 people while 1 person could also do the job.



Cleaning & Maintenance

• When not in use, cover the product with a protective cover to keep it clean and prolong its