

**MONEY BACK
GUARANTEE†**

Spectracide®

BUG STOP®

HOME BARRIER

Tratamiento de barrera para el hogar

Kills On Contact

Up To **12 Month***
Control for Cockroaches



ants

spiders

roaches

**Indoor PLUS Outdoor
Insect Control**

Active Ingredient: 0.025%
Gamma-Cyhalothrin
Other Ingredients 99.975%

Net 1.33 gal (170 fl oz / 5.0 L)

*For terms of guarantee,
see back panel.
†On non-porous surfaces

17-15420

KEEP OUT OF REACH OF CHILDREN

CAUTION

See back booklet for additional
precautionary statements.

MANTÉNGASE FUERA DEL ALCANCE DE LOS NIÑOS

PRECAUCIÓN

Consulte el folleto en la parte
posterior para conocer
las declaraciones preventivas adicionales.




RESEALABLE LABEL • PEEL HERE
ETIQUETA RESEALABLE • ABRIR AQUÍ

STOP. READ ENTIRE LABEL BEFORE USE.
ALTO. LEA TODA LA ETIQUETA ANTES DE USAR.

Spectracide

BUG STOP
HOME BARRIER
Tratamiento de barrera para el hogar

ACCUSHOT
Continuous Power Sprayer™



Extendable Wand
For Accuracy

Comfort • Power • Precision

Aim & Spray



Kills Ants, Roaches,
Spiders, Fleas & Ticks



Use Indoors
& as an Outdoor
Foundation Treatment



Water-Based,
Clear Formula



No Oily Residue



Leaves No Odor

**OPERATING
INSTRUCTIONS
FOR ACCUSHOT™
SPRAYER**



1. Remove sprayer from side holster. Unwrap the tubing.
2. Remove seal from top of cap. Unplug cap.
3. Securely snap the plug into hole on cap.
4. Remove plastic tab near top of sprayer to activate batteries.
5. Twist nozzle to adjust spray from **CLOSE** to **SPRAY** or **STREAM**.
6. When priming the sprayer, hold sprayer level to the ground. Sprayer may not prime if it is held at an angle. Once primed, it will spray in any direction.

**MONEY BACK
GUARANTEE**

'Guaranteed Results or Your Money Back

If you are not satisfied with this product for any reason, send your written request for a refund to the address below, together with the original dated store receipt showing the price you paid. Please allow 6-8 weeks for processing.

QUESTIONS & COMMENTS: Call 1-800-917-5438 or visit our website at www.spectracide.com

HOW TO USE THE ACCUSHOT SPRAYER

Aim toward target area to be treated, and away from people and pets. • To improve accuracy, use slider to extend wand. • Press the trigger to spray. • Release the trigger to stop spray. After use: 1. Twist nozzle completely to **CLOSE** position. 2. Secure sprayer tip down in holster. 3. Failure to adjust nozzle completely to **CLOSE** position and properly secure sprayer in holster may result in leakage and damage to property or injury to people or animals.

Keep reusable AccuShot™ Sprayer for use with Spectracide® Bug Stop® Home Barrier.

To replace batteries: 1. Use screwdriver to open battery compartment. 2. Remove used batteries and insert four new AA batteries in correct positions as marked per diagram inside of battery compartment. **Never** insert the positive end where the negative end belongs and vice versa. **Always** use a complete set of new batteries of the same type when replacing batteries. **Never** mix alkaline, carbon-zinc or rechargeable batteries. 3. Securely close battery compartment door. 4. **Always** follow manufacturer's recommendations for use and disposal of batteries.

Additional operating notes: • Do not submerge in water. • Before each use, inspect sprayer carefully — make sure hose is flexible and not kinked, worn or cracked and that all connections are tight. • When storing sprayer for prolonged periods, remove batteries.

NOTICE: To the extent consistent with applicable law, buyer assumes all responsibility for safety and use not in accordance with directions.

NOTA: Hasta el grado que sea compatible con la legislación pertinente, el comprador asume toda la responsabilidad para seguridad y uso que no estén de acuerdo con las instrucciones.

Distributed by Spectrum Group, Division of United Industries Corporation, PO Box 142642, St. Louis, MO 63114-0642

EPA Reg. No. 9688-258-8845 EPA Est. Nos. 9688-MO-1 (U), 58996-MO-1 (AE), 11623-GA-1 (CK), 11623-GA-3 (DN)

Circled letter is first letter of lot number. 17-15919 © 2015 UIC

PROOF OF PURCHASE

0 71121 96380 2