

TROUBLESHOOTING:

	Possible Cause	Corrective Action
Bulb will not light.	1. Bulb is burned out.	1. Replace light bulb.
	2. Power is off.	2. Make sure power supply is on.
	3. Cord not plugged in.	3. Make sure cord is plugged into the outlet.
	4. Circuit breaker off.	4. Make sure circuit breaker is to the 'on' position.
Fuse blows or circuit breaker trips when light is turned on.	1. Exposed wire	1. Discontinue use. Unplug unit from the wall and contact a qualified electrician

PRODUCT MAINTENANCE:


1. To clean simply wipe with a soft dry cloth.
2. Do not use any cleaners with chemicals, solvents or harsh abrasives.

LIMITED WARRANTY

The manufacturer warrants this portable luminaire to be free from defects in materials and workmanship for a period of one (1) year from date of purchase. This warranty applies only to the original consumer purchaser and only to products used in normal use and service. If this product is found to be defective, the manufacturer's only obligation, and your exclusive remedy, is the repair or replacement of the product at the manufacturer's discretion, provided that the product has not been damaged through misuse, abuse, accident, modifications, alterations, neglect or mishandling. This warranty shall not apply to any product that is found to have been improperly installed, setup, or used in any way not in accordance with the instruction supplied with the product. This warranty shall not apply to a failure of the product as a result of an accident, misuse, abuse, negligence, alteration, or faulty installation, or any other failure not relating to faulty material or workmanship. This warranty shall not apply to the finish on any portion of the product, such as surface and/or weathering, as this is considered normal wear and tear. **The manufacturer does not warrant and specially disclaims any warranty, whether express or implied, of fitness for a particular purpose, other than the warranty contained herein. The manufacturer specifically disclaims any liability and shall not be liable for any consequential or incidental loss or damage, including but not limited to any labor / expense costs involved in the replacement or repair of said product.**

INSTRUCTION MANUAL

Retro Floor Lamp



Thank you for purchasing this product

Thank you for purchasing this product. This product has been manufactured to the highest standards of safety and quality. The lampshade is made of metal material, and the lamp body is made of solid wood.

FEATURES:

1. Durable easy to maintain finish; simply wipe with a clean soft cloth to keep looking new.
2. Using 317 foot switch Makes this light easier to switch on and off and easier to operate
3. Popular E26 (E27) lamp holder may be fitted with a CFL equivalent energy-saving bulb..

QUESTIONS, PROBLEMS, MISSING PARTS:

Before returning to your local Home Depot, please call our Customer Service. Can solve your problem by mail, sales location.

In the sales platform, you can submit photos and less parts, we will help you to solve them as soon as possible.

CAUTION:

1. Before starting to assemble your portable luminaire, spread all parts out on a clean flat surface. Inspect each part for defects that may have occurred during shipping.

Important: Inspect the wire insulation for any cuts, abrasions or exposed copper that may have resulted during shipping. If there is a defect in the wire, DO NOT continue the assembly operation. Please call our Customer Service.

2. CONSULT A QUALIFIED ELECTRICIAN IF YOU HAVE ANY ELECTRICAL QUESTIONS.
3. Keep your receipt and these Instructions for Proof of Purchase.

TOOLS REQUIRED FOR ASSEMBLY:




1 ea—40-watt maximum 3-way type
A bulb (or CFL equivalent)
(not included)

PARTS INCLUDED FOR ASSEMBLY (parts are not to scale):

Assembly (A) X 1Set



Assembly (B) X 1Set



ASSEMBLY INSTRUCTIONS:

1. Take out the used accessories in the package and prepare for assembly. This product does not require any tools.
2. Connect the EB of Assembly (B) so that the wooden body of the lamp body is installed.
3. Fasten EA1 and EA so that Assembly (A) and Assembly (B) can complete the installation of the entire lamp.
4. If there are few accessories, you can remove the accessories from the spare bag and install them.
5. EB1 is to adjust the height of the lamp body.
6. Attaching the light source.

