


ASSEMBLY INSTRUCTION

W69177446

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which have come loose inside the carton during shipment. Identify and count all parts and compare with the part list below. Place all wooden furniture parts on a clean and flat soft surface, such as carpet or rug to prevent from being scratched.

LIST OF PARTS		
No	Description	Qty
1	Chair Back	2
2	Front Legs	2
3	Apron	4
4	Chair Seat	2
5	Stretcher	4

LIST OF PARTS		
No	Description	Qty
A	JCBC 	12
B	Spring washer 	12
C	Wood Screw 	14
D	Allen Key 	1
E	Wood Dowel 	12

IMPORTANT! Please ensure all bolts are inserted before tightening.

WARNING

- This Chair not suitable for Standing On
- Do Not over Tighten the bolts and screw

